



YAMAHA

PARTS LIST

YAMAHA CHAPPY

MODEL LB50UH ('76)
(TYPE 543)

FOR EUROPE

YAMAHA MOTOR CO., LTD.

COPY RIGHT: ALL RIGHTS RESERVED


NO PART OF THIS PUBLICATION MAY BE REPRODUCED WITHOUT PERMISSION.

FOREWORD

This Parts List related to the parts in use for the YAMAHA CHAPPY LB50IH (For SWITZERLAND Specifications). When you ordering replacement parts for the LB50IH, refer to this Parts List and write both part numbers and part names correctly.

1. Structure of Part No.

Yamaha parts are divided largely into two categories; general parts and standard parts, and each part No. has the following structure:



Note: Every standard No. begins with 9.

2. How to Use this Parts List

- (1) Except for steel balls (whose size is indicated in inches), the size of all parts is indicated in millimeters in the following manner.

Hose (rubber or vinyl) Inside diameter - length

O-ring Section area - inside diameter

Washer, shim, collar Inside diameter - outside diameter - thickness (length)

- (2) Parts, which are to be supplied in the form of assemblies, are listed with an indention of one letter's space, and a dot (.) is put

Example	Description	Q'ty
	CARBURETOR ASS'Y, left	1
	CARBURETOR ASS'Y, right	1
	. JET, pilot	2
	. NOZZLE, main	2
	...	
	. LEVER, starter, left	1
	. LEVER, starter, right	1

U. R.	Use size (thickness) and/or number as required
U. N.	Use as many as you need
T	Number of teeth in a gear
V	Voltage for light bulbs
S	"S" type oil seal or "S" type circlip
SD	"SD" type oil seal
SO	"SO" type oil seal
SW	"SW" type oil seal
E	"E" type circlip
R	"R" type circlip
F/No.	Frame No. (Applicable machine No.)

CONTENTS

ENGINE

Fig. 1	Crankcase • Cylinder	1
Fig. 2	Crankcase Cover	3
Fig. 3	Crank • Piston	5
Fig. 4	Clutch	9
Fig. 5	Transmission	11
Fig. 6	Shifter 1	13
Fig. 7	Shifter 2	15
Fig. 8	Kick Starter	17
Fig. 9	Intake	19
Fig. 10	Carburetor	21
Fig. 11	Exhaust	25
Fig. 12	Oil Pump	27
Fig. 13	Flywheel Magneto	29

CHASSIS

Fig. 14	Frame	33
Fig. 15	Rear Arm • Rear Cushion • Chain Case	37
Fig. 16	Stand • Footrest • Brake Pedal	39
Fig. 17	Front Fender • Rear Fender	41
Fig. 18	Front Fork	43
Fig. 19	Steering	45
Fig. 20	Handle • Wire	47
Fig. 21	Fuel Tank	51
Fig. 22	Oil Tank	53
Fig. 23	Seat • Under Cover	55
Fig. 24	Front Wheel	57
Fig. 25	Rear Wheel	61
Fig. 26	Head Lamp • Speedometer	65

Fig. 27	Carrier • Tail Lamp	67
Fig. 28	Electrical	69

OPTIONAL PARTS

Fig. 29	Leg Shield	73
---------	------------	----

NUMERICAL INDEX

Fig. 1	Crankcase • Cylinder	73
Fig. 2	Crank • Piston	73
Fig. 3	Clutch	73
Fig. 4	Transmission	73
Fig. 5	Shifter 1	73
Fig. 6	Shifter 2	73
Fig. 7	Kick Starter	73
Fig. 8	Intake	73
Fig. 9	Carburetor	73
Fig. 10	Exhaust	73
Fig. 11	Oil Pump	73
Fig. 12	Flywheel Magneto	73
Fig. 13	Frame	73
Fig. 14	Rear Arm • Rear Cushion • Chain Case	73
Fig. 15	Stand • Footrest • Brake Pedal	73
Fig. 16	Front Fender • Rear Fender	73
Fig. 17	Front Fork	73
Fig. 18	Steering	73
Fig. 19	Handle • Wire	73
Fig. 20	Fuel Tank	73
Fig. 21	Oil Tank	73
Fig. 22	Seat • Under Cover	73
Fig. 23	Front Wheel	73
Fig. 24	Rear Wheel	73
Fig. 25	Head Lamp • Speedometer	73

Fig. 1 CRANKCASE • CYLINDER





Fig. 1 CRANKCASE · CYLINDER



CRANKCASE · CYLINDER

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
1- 1	441-15111-01	CASE, crank left	1		
1- 2	441-15121-01	CASE, crank right	1		
1- 3	91810-05016	PIN, dowel (8.4-12-16)	2		
1- 4	92501-06050	SCREW, panhead	6		
1- 5	92501-06045	SCREW, panhead	2		
1- 6	92501-06035	SCREW, panhead	2		
1- 7	90116-06026	BOLT, cylinder holding (109-11361-00)	4		
1- 8	439-11351-00	GASKET, cylinder	1		
1- 9	439-11311-00	CYLINDER	1		
1-10	107-11181-01	GASKET, cylinder head	1		
1-11	439-11111-00	HEAD, cylinder	1		
1-12	92901-06200	WASHER, plain	4		
1-13	95301-06600	NUT, hexagon	4		
1-14	90340-12005	PLUG, drain (132-15351-00)	1		
1-15	90430-12038	GASKET, drain plug (132-15353-00)	1		
1-16	296-15128-00	HOLDER, right	1		
1-17	92501-08010	SCREW, panhead	1		
1-18	94701-00040	PLUG, spark (B-7HS)	1		


Fig. 2 CRANKCASE COVER



CRANKCASE COVER

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
2- 1	441-15411-00	COVER, crankcase left	1		
2- 2	91810-02015	PIN, dowel (6.4-10-15)	4		
2- 3	92501-06100	SCREW, panhead	1		
2- 4	92501-06045	SCREW, panhead	3		
2- 5	395-15415-00	COVER, generator	1		
2- 6	98601-05012	SCREW, ovalhead	3		
2- 7	441-15417-01	COVER, cap	1		
2- 8	441-15421-00	COVER, crankcase right	1		
2- 9	296-15451-00	GASKET, crankcase cover	1		
2-10	92501-06025	SCREW, panhead	6		
2-11	92501-06040	SCREW, panhead	1		
2-12	353-15362-00	PLUG, oil level	1		
2-13	93210-21190	O-RING (2.6-20.6)	1		
2-14	439-15378-00	HOLDER	1		
2-15	592-15631-00	GAUGE, level	1		
2-16	93210-19123	O-RING (2.4-19.0)	1		


Fig. 3 CRANK · PISTON



CRANK · PISTON

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
3- 1	441-11400-01	CRANK ASS'Y	1		
3- 2	441-11412-00	. CRANK, left	1		
3- 3	441-11422-00	. CRANK, right	1		
3- 4	126-11651-00	. ROD, connecting	1		
3- 5	93310-41810	. BEARING, big end	1		
3- 6	257-11681-00	. PIN, crank	1		
3- 7	93310-11202	BEARING, small end	1		
3- 8	353-11631-01-96	PISTON (39.96mm STD)	1	U.R.	
	353-11631-01-98	PISTON (39.98mm STD)	1		
	353-11635-01	PISTON (40.25mm 1st O.S.)	1		Alternate Parts
	353-11636-01	PISTON (40.50mm 2nd O.S.)	1		Alternate Parts
	353-11637-01	PISTON (40.75mm 3rd O.S.)	1		Alternate Parts
	353-11638-01	PISTON (41.00mm 4th O.S.)	1		Alternate Parts
3- 9	102-11633-01	PIN, piston	1		
3-10	93450-13022	CLIP (132-11634-00)	2		
3-11	260-11610-00	PISTON RING SET (STD)	1s		
	260-11610-10	PISTON RING SET (1st O.S.)	1s		Alternate Parts
	260-11610-20	PISTON RING SET (2nd O.S.)	1s		Alternate Parts
	260-11610-30	PISTON RING SET (3rd O.S.)	1s		Alternate Parts
	260-11610-40	PISTON RING SET (4th O.S.)	1s		Alternate Parts
3-12	93306-20418	BEARING (B6204C3)	2		
3-13	93102-20009	OIL SEAL (SD-20-35-7)	1		
3-14	90201-12535	WASHER, plate	1		
3-15	92901-12100	WASHER, spring	1		
3-16	90170-12175	NUT, hexagon	1		
3-17	90280-03017	KEY, woodruff (146-11545-00)	1		
3-18	93103-28011	OIL SEAL (SW-28-40-8)	1		
3-19	90387-20345	COLLAR, distance (132-16136-01)	1		
3-20	441-13178-00	GEAR, drive	1		

Fig. 3 CRANK · PISTON




CRANK · PISTON

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
3-21	401-16111-00	GEAR, primary drive (19T)	1		
3-22	90208-12015	SPRING, belleville (164-16119-00) 1			
3-23	90179-12044	NUT, lock (353-16144-00)	1		
3-24	93603-08072	PIN, dowel (2.5-17.8)	1		
3-25	90282-05055	KEY (353-11546-00)	1		

ALTERNATE PARTS

3-26	439-11630-00	PISTON ASS'Y (STD)	1s	Ref. No. 8,9,10,11
	439-11630-10	PISTON ASS'Y (1st O.S.)	1s	
	439-11630-20	PISTON ASS'Y (2nd O.S.)	1s	
	439-11630-30	PISTON ASS'Y (3rd O.S.)	1s	
	439-11630-40	PISTON ASS'Y (4th O.S.)	1s	Ref. No. 4,5,6,7
3-27	439-11650-00	CONNECTING ROD ASS'Y	1s	


Fig. 4 CLUTCH



CLUTCH

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
4- 1	441-16301-00	CLUTCH ASS'Y	1		
4- 2	441-16150-01	PRIMARY DRIVEN GEAR COMP. (68T)	1		
4- 3	93210-98202	O-RING (5.33-97.76)	1		
4- 4	90201-23315	PLATE thrust (116-16153-00)	1		
4- 5	122-16164-00	PLATE, thrust (17.2-30-2)	2		
4- 6	353-16371-00	BOSS, clutch	1		
4- 7	131-16367-00	RING, cushion	3		
4- 8	131-16321-00	PLATE, friction	3		
4- 9	257-16324-00	PLATE, clutch	2		
4-10	353-16351-00	PLATE, pressure	1		
4-11	90119-05001	BOLT, hexagon with washer	4		
4-12	90501-20125	SPRING, clutch (132-16333-00)	4		
4-13	90208-12015	SPRING, belleville (164-16119-00)	1		
4-14	90170-12060	NUT, clutch boss (137-16377-00)	1		
4-15	137-16356-00	ROD, push 1	1		
4-16	90560-17150	SPACER	1		
4-17	93503-16010	BALL (3/16 inch)	1		
4-18	353-16357-00	ROD, push 2	1		
4-19	257-15389-00	SEAL, push rod	1		
4-20	95301-06700	NUT, hexagon	1		
4-21	90113-06013	SCREW, adjusting (241-16343-00)	1		
4-22	241-16341-01	SCREW, push	1		
4-23	353-16396-00	HOUSING, push screw	1		
4-24	92501-06015	SCREW, panhead	1		
4-25	93104-11028	OIL SEAL (SO-10.5-15-3)	1		
4-26	451-16342-00	LEVER, push	1		
4-27	90506-07066	SPRING, lever return (257-16345-00)	1		
4-28	132-16346-00	HOOK, spring	1		


Fig. 5 TRANSMISSION



TRANSMISSION

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
5- 1	441-17411-00	AXLE, main (12T)	1		
5- 2	353-17141-01	GEAR, 4th pinion (24T)	1		
5- 3	93440-16030	CIRCLIP (257-17414-00)	1		
5- 4	353-17131-00	GEAR, 3rd pinion (21T)	1		
5- 5	353-17121-00	GEAR, 2nd pinion (17T)	1		
5- 6	615-45533-01-04	WASHER, drive shaft (12, 3-22-0.4)	1		
5- 7	93410-12003	CIRCLIP (S-12)	2		
5- 8	93306-20303	BEARING (6203Z)	1		
5- 9	296-17471-00	PLATE, bearing cover	1		
5-10	92501-06012	SCREW, panhead	2		
5-11	441-17420-00	DRIVE AXLE COMP.	1		
5-12	441-17421-00	AXLE, drive	1		
5-13	441-17221-00	GEAR 2nd wheel (34T)	1		
5-14	441-17231-00	GEAR, 3rd wheel (30T)	1		
5-15	93440-16030	CIRCLIP (257-17414-00)	1		
5-16	353-17241-00	GEAR, 4th wheel (27T)	1		
5-17	441-17211-00	GEAR, 1st wheel (27T, 39T)	1		
5-18	90201-13415	WASHER, plate (t-0.7)	1		
5-19	93410-13004	CIRCLIP (S-13)	1		
5-20	93306-30305	BEARING (6303)	1		
5-21	93102-26042	OIL SEAL (SD-26-38-5)	1		
5-22	90387-17228	COLLAR, distance	1		
5-23	257-17461-30	SPROCKET, drive (13T)	1	U.R.	STD
	257-17461-40	SPROCKET, drive (14T)			
	257-17461-50	SPROCKET, drive (15T)			
5-24	90215-13019	WASHER, lock (257-17464-00)	1		
5-25	90179-12181	NUT, lock (257-17463-00)	1		


Fig. 6 SHIFTER 1



SHIFTER 1


Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
6- 1	511-18541-00	CAM, shift	1		
6- 2	93604-22050	PIN, dowel (4-21.8)	4		
6- 3	90249-04039	PIN (174-18544-00)	1		
6- 4	93430-03014	CIRCLIP (E-2.5)	1		
6- 5	296-18561-00	PLATE, side	1		
6- 6	93430-09019	CIRCLIP (E-9)	1		
6- 7	93315-23208	BEARING	1		
6- 8	425-18511-00	FORK, shift 1	1		
6- 9	93606-14081	PIN, dowel (6-14.2)	2		
6-10	91401-25017	PIN, cotter	1		
6-11	441-18562-00	PLATE, stopper	1		
6-12	92501-06015	SCREW, panhead	2		
6-13	441-18140-00	STOPPER LEVER ASS'Y	1		
6-14	90109-06001	BOLT, stopper (132-18177-00)	1		
6-15	90506-09126	SPRING, tension	1		
6-16	132-16346-00	HOOK, spring	1		
6-17	441-18531-01	BAR, shift fork guide	1		
6-18	93210-08006	O-RING (1.9-7.8)	1		
6-19	93430-10016	CIRCLIP (E-10)	1		
6-20	353-18512-01	FORK, shift 2	1		

Fig. 7 SHIFTER 2



Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
7- 1	441-18101-00	CHANGE SHAFT ASS'Y	1		
7- 2	90506-08122	SPRING, tension	1		
7- 3	90508-32263	SPRING, torsion	1		
7- 4	93101-12004	OIL SEAL (S-12-22-5)	1		
7- 5	90201-12575	WASHER, plate	1		
7- 6	93430-10016	CIRCLIP (E-10)	1		
7- 7	90149-08094	SCREW	1		
7- 8	95301-08600	NUT, hexagon	1		
7- 9	441-18111-00-93	PEDAL, change	1		
7-10	132-18113-01	COVER, change pedal	1		
7-11	97321-06020	BOLT	1		


Fig. 8 KICK STARTER



KICK STARTER

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
8- 1	296-15660-00	KICK AXLE ASS'Y	1		
8- 2	296-15641-00	GEAR, kick (22T)	1		
8- 3	90206-19027	WASHER, wave (296-15643-00)	1		
8- 4	296-15644-00	SHIM (19-26-1)	1		
8- 5	93410-19015	CIRCLIP (S-19)	2		
8- 6	296-15671-00	WHEEL, ratchet	1		
8- 7	90468-26046	CLIP (296-15687-00)	1		
8- 8	296-15664-00	GUIDE, kick spring	1		
8- 9	90508-26136	SPRING (304-15665-00)	1		
8-10	132-15676-00	COVER, kick spring	1		
8-11	93410-15005	CIRCLIP (S-15)	1		
8-12	93109-15001	OIL SEAL (SDO-15-26-6)	1		
8-13	439-15610-02-93	KICK CRANK ASS'Y	1		
8-14	122-15612-02	LEVER, kick	1		
8-15	90504-18005	SPRING (132-15625-01)	1		
8-16	90209-10108	WASHER (132-15616-01)	1		
8-17	93440-10028	CLIP (132-15617-00)	1		
8-18	156-15618-01	COVER, kick lever	1		
8-19	97311-06025	BOLT, hexagon	1		


Fig. 9 INTAKE



INTAKE

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
9- 1	439-14411-00	CASE, air cleaner	1		
9- 2	439-14451-00	ELEMENT, air cleaner	1		
9- 3	439-14412-00	CAP, cleaner case	1		
9- 4	92501-06008	SCREW, panhead	2		
9- 5	92901-06100	WASHER, spring	3		
9- 6	97321-06010	BOLT	1		
9- 7	90506-06075	BAND (367-14455-01)	1		
9- 8	439-14453-01	JOINT, air cleaner	1		
9- 9	90467-20023	BAND (296-14455-00)	1		
9-10	439-13565-03	JOINT	1		
9-11	353-13621-00	PACKING, valve seat	2		
9-12	353-13610-01	REED VALVE ASS'Y	1		
9-13	314-13613-00	. REED, valve	1		
9-14	314-13616-01	. STOPPER, reed valve	1		
9-15	98512-03008	. SCREW, panhead	2		
9-16	92901-03100	. WASHER, spring	2		
9-17	92501-06025	SCREW, panhead	4		
9-18	92901-06100	WASHER, spring	4		


Fig. 10 CARBURETOR



CARBURETOR

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
10- 1	439-14101-02	CARBURETOR ASS'Y	1		
10- 2	137-14141-12	. NOZZLE, main (E-2)	1		
10- 3	127-14143-19	. JET, main (#95)	U.R. 1		STD
	127-14143-20	. JET, main (#100)			
	127-14143-21	. JET, main (#105)			
10- 4	193-14142-12	. JET, pilot (#12, 5)	1		
10- 5	116-14190-12	. VALVE SEAT ASS'Y	1		
10- 6	127-14195-00	. WASHER, valve seat	1		
10- 7	439-14185-00	. FLOAT	1		
10- 8	439-14186-00	. PIN, float	1		
10- 9	439-14184-00	. GASKET, float chamber	1		
10-10	439-14181-00	. BODY, float chamber	1		
10-11	98502-04014	. SCREW, panhead	3		
10-12	92901-04100	. WASHER, spring	3		
10-13	439-14112-15	. VALVE, throttle	1		
10-14	127-14116-09	. NEEDLE (3G9-3)	1		
10-15	127-14137-00	. CLIP	1		
10-16	439-14136-00	. SEAT, spring	1		
10-17	439-14131-00	. SPRING, throttle	1		
10-18	439-14198-00	. GASKET, mixing chamber	1		
10-19	439-14158-00	. TOP, mixing chamber	1		
10-20	92901-04100	. WASHER, spring	4		
10-21	98501-04010	. SCREW, panhead	4		
10-22	127-14123-00	. SCREW, air adjusting	1		
10-23	127-14134-00	. SPRING, air adjusting	1		
10-24	98302-03012	. SCREW, throttle adjusting	1		
10-25	620-14133-00	. SPRING, throttle stop	1		
10-26	127-14171-00	. PLUNGER, starter	1		
10-27	127-14135-00	. SPRING, plunger	1		


Fig. 10 CARBURETOR



CARBURETOR

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
10-28	439-14174-01	. CAP, plunger	1		
10-29	439-14155-00	. GUIDE, cable	1		
10-30	127-14161-00	. NUT, wire adjusting	1		
10-31	432-14124-00	. SCREW, wire adjusting	1		
10-32	439-14169-00	. CAP	1		
10-33	439-14125-00	. SCREW, clip	1		
10-34	440-14197-00	PIPE, air vent (5.0-75)	1		
10-35	353-14196-00	PIPE, over flow (3.0-150)	1		


Fig. 11 EXHAUST



EXHAUST

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
11- 1	543-14710-00	MUFFLER ASS'Y	1		
11- 2	132-14714-01	GASKET, muffler joint	1		
11- 3	395-14713-00	NUT, muffler joint	1		
11- 4	439-14611-02	PIPE, exhaust	1		
11- 5	122-14612-02	NUT, ring	1		
11- 6	132-14613-00	GASKET, exhaust	1		
11- 7	97321-08018	BOLT, hexagon	1		
11- 8	92901-08200	WASHER, plain	1		
11- 9	441-14718-01	PROTECTOR, muffler	1		
11-10	91903-06010	SCREW, bind	3		
11-11	90202-06010	WASHER (178-14766-00)	6		
11-12	439-14729-00	EMBLEM, protector	1		
11-13	90202-04003	WASHER, plate (174-28316-00)	2		
11-14	90183-04005	NUT (116-28317-01)	2		
11-15	441-14747-00	DAMPER, muffler	1		


Fig. 12 OIL PUMP



OIL PUMP

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
12- 1	442-13101-00	OIL PUMP ASS'Y	1		
12- 2	93210-26240	. O-RING (2.4-25.8)	1		
12- 3	93101-10001	. OIL SEAL (S-10-21-5)	1		
12- 4	296-13124-00	. GEAR, worm wheel (56T)	1		
12- 5	93430-07012	. CIRCLIP (E-7)	1		
12- 6	93603-14026	. PIN, dowel (3-14)	1		
12- 7	98901-04008	. SCREW, bind	1		
12- 8	90430-04004	. GASKET (137-13187-00)	1		
12- 9	296-13147-00	. SHIM	1		
12-10	384-13138-00	. PLATE, adjusting	1		
12-11	90170-10105	. NUT, hexagon	1		
12-12	384-13118-00	. BOLT, adjusting	1		
12-13	98501-05020	SCREW, panhead	1		
12-14	98501-05035	SCREW, panhead	1		
12-15	439-15416-02	COVER, oil pump 1	1		
12-16	92501-06015	SCREW, panhead	1		
12-17	92701-06012	SCREW, flathead	1		
12-18	439-15426-02	COVER, oil pump 2	1		
12-19	92501-06015	SCREW, panhead	2		
12-20	90480-11057	GROMMET	1		
12-21	90445-05206	HOSE	1		
12-22	384-13174-00	HOLDER, oil pipe	1		
12-23	90480-16179	GROMMET	1		

Fig. 13 FLYWHEEL MAGNETO



FLYWHEEL MAGNETO

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
13- 1	511-81300-20	FLYWHEEL MAGNETO ASS'Y ..	1		
13- 2	511-81350-20	. ROTOR ASS'Y	1		
13- 3	511-81309-20	. BASE, magneto	1		
13- 4	511-81312-20	. COLL, source	1		
13- 5	511-81313-20	. COIL, lighting	1		
13- 6	110-81348-21	. SCREW (4-25)	4		
13- 7	437-81321-20	. CONTACT BREAKER ASS'Y ..	1		
13- 8	110-81346-21	. SCREW (4-10)	1		
13- 9	511-81325-20	. CONDENSER	1		
13-10	116-81331-20	. LUBRICATOR	1		
13-11	110-81347-21	. SCREW (4-10)	1		
13-12	109-81328-20	. CLAMP, lead	1		
13-13	110-81345-21	. SCREW (4-6)	1		
13-14	511-81315-20	. LEAD WIRE ASS'Y	1		
13-15	90480-16110	. GROMMET (164-82597-00) ...	1		
13-16	98701-05015	. SCREW, flathead	2		

YAMAHA
PARTS

Fig. 13 FLYWHEEL MAGNETO

Ref. No.	Part No.	Description	Qty.	Remarks
----------	----------	-------------	------	---------




Fig. 14 FRAME

Ref. No.	Part No.	Description	Qty.	Remarks
----------	----------	-------------	------	---------




CHASSIS

YAMAHA
PARTS

Fig. 14 FRAME

FRAME



Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
14- 1	1F0-21110-00-26	FRAME COMP.	1		Competition Yellow
	1F0-21110-00-29	FRAME COMP.	1		Candy Blue
	1F0-21110-00-98	FRAME COMP.	1		Frosting Black
	1F0-21110-00-E1	FRAME COMP.	1		Chappy Red
					Yamaha Black
14- 2	439-21421-00-33	STAY, engine 2	1		
14- 3	90109-08386	BOLT, hexagon	1		
14- 4	90170-08158	NUT, hexagon	1		
14- 5	92901-08100	WASHER, spring	3		
14- 6	95821-08120	BOLT, flange (127-21483-00) ...	1		
14- 7	90105-08025	BOLT, washer based head hexagon	1		
14- 8	439-28321-00	STAY, under cover	1		
14- 9	95821-08015	BOLT, flange	2		
14-10	439-28385-00	COVER, under	1		
14-11	97323-06015	BOLT, hexagon	2		
14-12	90201-06052	WASHER, plate (136-22316-00) ...	2		
14-13	90480-21038	GROMMET (296-15486-00)	1		
14-14	439-28386-00	COVER, front	1		
14-15	97301-06020	BOLT, hexagon	1		
14-16	92901-06100	WASHER, spring	1		
14-17	92901-06600	WASHER, plate	1		
14-18	1F0-28100-10	TOOL ASS'Y	1		
14-19	95701-08100	NUT, hexagon	1		
14-20	439-23319-00	HOLDER, wire	1		
14-21	97301-06015	BOLT, hexagon	1		
14-22	92901-06600	WASHER, plate	1		
14-23	439-23480-00	STEERING LOCK ASS'Y	1		
14-24	92701-06015	SCREW, flathead	2		
14-25	1F0-28328-00	EMBLEM, main switch	1		

Fig. 14 FRAME






Fig. 15 REAR ARM - CHAIN CASE FRAME



Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
----------	-----------	-------------	------	------------------------	---------

14-26	561-24723-00	DAMPER, seat	2		
14-27	90480-10178	GROMMET	2		

Fig. 15 REAR ARM · REAR CUSHION · CHAIN CASE



REAR ARM · REAR CUSHION · CHAIN CASE

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
15- 1	563-22110-00-33	REAR ARM COMP.	1		Yamaha Black
15- 2	102-22123-00	BUSHING, rear arm	2		
15- 3	353-22141-01	SHAFT, pivot	1		
15- 4	95601-10100	NUT, U	1		
15- 5	395-22151-00	SEAL, guard	1		
15- 6	561-22210-20	REAR CUSHION ASS'Y	2		
15- 7	95304-12800	NUT, cap	2		
15- 8	90201-12190	WASHER, plate (122-22243-00)	4		
15- 9	95304-12800	NUT, hexagon	2		
15-10	90201-12190	WASHER, plate (122-22243-00)	2		
15-11	1F0-22310-00	CHAIN CASE ASS'Y	1		
15-12	98501-05012	SCREW, panhead	2		
15-13	92901-05100	WASHER, spring	2		
15-14	92901-05600	WASHER, plate	2		


Fig. 16 STAND · FOOTREST · BRAKE PEDAL



STAND · FOOTREST · BRAKE PEDAL

Yamaha Black	
16- 1	439-27111-02-33 STAND, main 1
16- 2	336-27112-00 SHAFT, main stand 1
16- 3	90508-26037 SPRING, torsion (156-27216-00) 1
16- 4	563-27211-00-93 PEDAL, brake 1
16- 5	93430-12008 CIRCLIP (E-12) 1
16- 6	288-27231-00 ROD, brake 1
16- 7	92901-06600 WASHER, plate 2
16- 8	91401-20012 PIN, cotter 1
16- 9	90501-10245 SPRING, compression (180-27236-00) 1
16-10	90249-12008 PIN (156-27237-00) 1
16-11	90179-06176 NUT 1
16-12	102-27114-00 STOPPER, main stand 1
16-13	439-27411-00 FOOTREST 1
16-14	441-27413-00 COVER, footrest 2
16-15	97301-08015 BOLT, hexagon 1
16-16	92901-08100 WASHER, spring 1
16-17	90506-28100 SPRING, tension (276-27316-00) 1


Fig. 17 FRONT FENDER · REAR FENDER



FRONT FENDER · REAR FENDER

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
17- 1	441-21510-00-93	FRONT FENDER COMP.	1		
17- 2	97301-06012	BOLT, hexagon	4		
17- 3	92901-06100	WASHER, spring	4		
17- 4	441-21611-00-93	REAR FENDER COMP.	1		
17- 5	97301-06012	BOLT, hexagon	2		
17- 6	92901-06100	WASHER, spring	2		
17- 7	92901-06600	WASHER, plate	2		

Fig. 18 FRONT FORK



FRONT FORK


Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
18- 1	439-23101-01-35	FRONT FORK ASS'Y	1		Silver
18- 2	439-23136-00-35	TUBE, outer left	1		Silver
18- 3	439-23126-00-35	TUBE, outer right	1		Silver
18- 4	207-23147-00	O-RING	2		
18- 5	367-23141-60	SPRING	1		
18- 6	290-23149-00	WASHER	1		
18- 7	367-23166-60	SPACER	1		
18- 8	439-23124-00	TUBE, inner left	1		
18- 9	439-23134-00	TUBE, inner right	1		
18-10	109-23125-00	METAL, slide	2		
18-11	290-23150-01	OUTER NUT COMP.	2		
18-12	109-23145-01	OIL SEAL	2		
18-13	290-23144-00	SEAL, dust	2		
18-14	122-23163-00	PACKING	2		
18-15	354-23115-90	COVER, guide	2		
18-16	307-23114-00	PACKING	2		
18-17	207-23112-00	WASHER, cap	2		
18-18	395-23111-00	BOLT, cap	2		
18-19	439-23340-01-33	UNDER BRACKET COMP.	1		Yamaha Black
18-20	122-23346-01	BOLT	1		
18-21	439-23121-00-26	COVER, upper left	1		Competition Yellow
	439-23121-00-29	COVER, upper left	1		Candy Blue
	439-23121-00-98	COVER, upper left	1		Frosting Black
	439-23121-00-E1	COVER, upper left	1		Chappy Red
18-22	439-23131-00-26	COVER, upper right	1		Competition Yellow
	439-23131-00-29	COVER, upper right	1		Candy Blue
	439-23131-00-98	COVER, upper right	1		Frosting Black
	439-23131-00-E1	COVER, upper right	1		Chappy Red
18-23	90338-04010	PLUG, blind (290-83329-00)	2		

Fig. 19 STEERING

STEERING

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
19- 1	164-23462-00	SEAL, dust	1		
19- 2	156-23411-00	RACE, ball 1	1		
19- 3	156-23412-00	RACE, ball 2	1		
19- 4	93501-04011	BALL (1/4 inch)	19		
19- 5	122-23411-00	RACE, ball 1	1		
19- 6	122-23412-00	RACE, ball 2	1		
19- 7	93503-16010	BALL (3/16 inch)	22		
19- 8	122-23416-00	COVER, ball race	1		
19- 9	90179-25051	NUT (122-23453-00)	1		
19-10	439-23435-01	CROWN, handle	1		
19-11	90209-10021	WASHER (122-23443-00)	1		
19-12	90105-10006	BOLT, washer based head hexagon (122-23451-00)	1		
19-13	122-23441-00	HOLDER, handle upper	2		
19-14	462-23442-00	HOLDER, handle under	2		
19-15	95301-10600	NUT, hexagon	2		
19-16	92901-10100	WASHER, spring	2		
19-17	97301-06035	BOLT, hexagon	4		
19-18	92901-06600	WASHER, plate	4		


Fig. 20 HANDLE · WIRE



HANDLE · WIRE

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
20-1	439-26111-00	HANDLE	1		
20-2	395-26241-00	GRIP, left	1		
20-3	441-82710-91	LEVER HOLDER ASS'Y, left ..	1		
20-4	425-83912-00	. LEVER, left	1		
20-5	98501-05025	. SCREW, panhead	1		
20-6	395-83913-00	. COLLAR, lever	1		
20-7	95301-05600	. NUT, hexagon	1		
20-8	439-83941-01	LEVER, starter	1		
20-9	90209-10131	WASHER	1		
20-10	92901-06200	WASHER, plain	1		
20-11	97323-06008	BOLT, hexagon (137-83945-00)	1		
20-12	395-83980-00	FRONT STOP SWITCH ASS'Y ..	1		
20-13	395-82920-92	LEVER HOLDER ASS'Y, right ..	1		
20-14	395-83922-01	. LEVER, right	1		
20-15	98501-05025	. SCREW, panhead	1		
20-16	395-83913-00	. COLLAR, lever	1		
20-17	95301-05600	. NUT, hexagon	1		
20-18	395-83980-00	FRONT STOP SWITCH ASS'Y ..	1		
20-19	395-26243-00	TUBE, guide	1		
20-20	150-26249-00	RING, leaf	1		
20-21	395-26242-00	GRIP, right	1		
20-22	439-26311-00	WIRE, throttle 1 (480mm)	1		
20-23	95301-10700	NUT, hexagon	1		
20-24	137-26261-01	CYLINDER, wire	1		
20-25	97301-06015	BOLT, hexagon	1		
20-26	92901-06100	WASHER, spring	1		
20-27	92901-06600	WASHER, plate	1		
20-28	439-26321-00	WIRE, pump (140mm)	1		
20-29	439-26312-00	WIRE, throttle 2 (160mm)	1		

Fig. 20 HANDLE · WIRE




HANDLE · WIRE

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
20-30	439-26341-00	WIRE, brake front (965mm)	1		
20-31	90123-08013	BOLT (156-26346-00)	1		
20-32	395-26323-00	NUT, adjusting	2		
20-33	90123-06011	BOLT (109-26345-00)	1		
20-34	90179-06143	NUT (109-26344-00)	1		
20-35	441-26335-00	WIRE, clutch (805mm)	1		
20-36	164-26363-00	END, wire	1		
20-37	439-26331-00	WIRE, starter (710mm)	1		
20-38	341-26397-01	BAND	2		
20-39	90338-07011	PLUG (116-83931-00)	1		
20-40	266-26290-10	BACK MIRROR ASS'Y, left	1		

OPTIONAL PARTS

20-41	395-26290-00	BACK MIRROR ASS'Y, right ...	1		
-------	--------------	------------------------------	---	--	--


Fig. 21 FUEL TANK



FUEL TANK


Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
21- 1	561-24111-00	TANK, fuel	1		
21- 2	439-24611-00	BODY, cap	1		
21- 3	439-24615-00	GASKET, plate 1	1		
21- 4	90430-02073	GASKET, plate 2 (439-24616-00)	1		
21- 5	439-24311-00	PIPE, fuel	1		
21- 6	168-24311-00	PIPE, fuel	1		
21- 7	90467-08003	CLIP (101-24356-00)	6		
21- 8	561-24173-00	BAND, tank fitting	1		
21- 9	439-24500-00	FUEL COCK ASS'Y	1		
21-10	266-24523-00	. VALVE	1		
21-11	439-24524-00	. LEVER	1		
21-12	439-24525-00	. PLATE, spring	1		
21-13	98503-03006	. SCREW, panhead	2		
21-14	266-24522-00	. GASKET	1		
21-15	395-24521-00	. CUP, filter	1		
21-16	98501-06015	SCREW, panhead	2		
21-17	92901-06100	WASHER, spring	2		
21-18	90445-09304	HOSE (174-21766-00)	1		5-310
21-19	439-24317-00	PIPE 7	1		
21-20	439-24182-00	DAMPER, locating 2	2		

Fig. 22 OIL TANK



Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
22- 1	561-21751-01	TANK, oil	1		
22- 2	296-21771-01	BODY, cap	1		
22- 3	296-21772-00	GASKET, cap	1		
22- 4	90445-09300	HOSE (5-355)	1		
22- 5	90504-06020	SPRING, compression	1		
22- 6	90467-08003	CLIP (101-24356-00)	2		
22- 7	90445-09113	HOSE (296-24311-00)	1		5-485
22- 8	561-21755-00	CLAMP, tube connecting	1		
22- 9	561-24119-00	TUBE, connecting	1		
22-10	439-21759-00	GROMMET	1		
22-11	439-24181-00	DAMPER, locating 1	2		
22-12	439-21778-00	DAMPER, locating	2		
22-13	341-82594-00	CLAMP	1		


Fig. 23 SEAT · UNDER COVER



SEAT · UNDER COVER

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
23- 1	1F2-24710-00	SINGLE SEAT ASS'Y	1		
23- 2	1F2-24711-00	COVER, single seat	1		
23- 3	561-24726-00	HINGE, seat	1		
23- 4	561-24768-02	STOPPER, pin	1		
23- 5	92901-06100	WASHER, spring	2		
23- 6	95301-06600	NUT, hexagon	2		
23- 7	97301-06012	BOLT, hexagon	2		
23- 8	92901-06600	WASHER, plate	2		
23- 9	91502-05100	PIN, clevis	1		
23-10	296-24723-00	DAMPER, seat	2		
23-11	214-24724-00	DAMPER, seat	2		
23-12	395-28185-00	LID	1		
23-13	561-24796-00-26	COVER, seat under	1		Competition Yellow
	561-24796-00-29	COVER, seat under	1		Candy Blue
	561-24796-00-98	COVER, seat under	1		Frosting Black
	561-24796-00-E1	COVER, seat under	1		Chappy Red
23-14	561-21783-00	EMBLEM, cover	1		
23-15	97301-06035	BOLT, hexagon	1		
23-16	90204-05001	WASHER, spring (117-21713-01)	1		
23-17	92901-06600	WASHER, plate	1		
23-18	90387-06513	COLLAR	1		
23-19	561-21278-00	MOLD, cover	1		
23-20	561-24728-01	BRACKET, seat	1		
23-21	92901-06100	WASHER, spring	2		
23-22	95301-06600	NUT, hexagon	2		
23-23	561-24705-00	SEAT BRACKET ASS'Y	1		
23-24	341-24818-00	HOOK, helmet	1		
23-25	97301-06025	BOLT, hexagon	1		
23-26	92901-06100	WASHER, spring	1		
23-27	92901-06600	WASHER, plate	1		


Fig. 24 FRONT WHEEL



FRONT WHEEL

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
24- 1	439-25111-00	HUB, front	1		
24- 2	395-25337-00-35	PANEL, wheel 1	1		Silver
24- 3	395-25347-00-35	PANEL, wheel 2	1		Silver
24- 4	90101-08249	BOLT, hexagon	4		
24- 5	92901-08100	WASHER, spring	8		
24- 6	95301-08600	NUT, hexagon	8		
24- 7	97321-08015	BOLT, hexagon	4		
24- 8	92901-08600	WASHER, plate	4		
24- 9	94140-08138	TIRE (4.00-8-4PR)	1		
24-10	94240-08044	TUBE (4.00-8)	1		
24-11	195-25115-00	FLANGE, spacer	1		
24-12	90560-10104	SPACER, bearing (439-25117-00)	1		
24-13	93306-30003	BEARING (6300Z)	2		
24-14	93106-20001	OIL SEAL (DD-20-35-7)	1		
24-15	93105-47007	OIL SEAL (SDD-47-58-7)	1		
24-16	93410-20009	CIRCLIP (S-20)	1		
24-17	90201-20269	WASHER, plate (183-25147-00)	2		
24-18	183-25149-00	CLUTCH, meter	1		
24-19	439-25135-00	GEAR, drive (26T)	1		
24-20	342-25121-00	PLATE, brake shoe	1		
24-21	296-25330-00	BRAKE SHOE COMP.	2		
24-22	122-25351-01	CAM SHAFT	1		
24-23	90506-16034	SPRING, tension (102-25333-00)	2		
24-24	109-25155-00	LEVER, cam shaft	1		
24-25	90101-06278	BOLT, hexagon	1		
24-26	92901-06600	WASHER, plate	1		
24-27	92901-06100	WASHER, spring	1		
24-28	95301-06600	NUT, hexagon	1		
24-29	90201-07076	WASHER, plate (183-25146-00)	1		


Fig. 24 FRONT WHEEL



FRONT WHEEL

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
24-30	439-25138-00	GEAR, meter (15T)	1		
24-31	93210-14104	O-RING (2, 4-13.8)	1		
24-32	109-25136-00	BUSHING	1		
24-33	93104-07003	OIL SEAL (SO-7-14-4)	1		
24-34	102-25137-00	RING, stop	1		
24-35	90387-10081	COLLAR (128-25183-00)	1		
24-36	439-25181-00	SHAFT, wheel	1		
24-37	90171-10004	NUT, castle (353-25182-00)	1		
24-38	91401-20020	PIN, cotter	1		


Fig. 25 REAR WHEEL



REAR WHEEL

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
25- 1	439-25311-00	HUB, rear	1		
25- 2	395-25337-00-35	PANEL, wheel 1	1		Silver
25- 3	395-25347-00-35	PANEL, wheel 2	1		Silver
25- 4	90101-08249	BOLT, hexagon	4		
25- 5	92901-08100	WASHER, spring	8		
25- 6	95301-08600	NUT, hexagon	8		
25- 7	97321-08015	BOLT, hexagon	4		
25- 8	92901-08600	WASHER, plate	4		
25- 9	94140-08138	TIRE (4.00-8-4PR)	1		
25-10	94240-08044	TUBE (4.00-8)	1		
25-11	109-25315-00	FLANGE, spacer	1		
25-12	90560-12110	SPACER (439-25317-00)	1		
25-13	93306-30103	BEARING (6301Z)	2		
25-14	93104-21016	OIL SEAL (SO-21-37-7)	1		
25-15	93106-20002	OIL SEAL (DD-20-37-8)	1		
25-16	102-25321-00-38	PLATE, brake shoe	1		
25-17	122-25351-01	CAM SHAFT	1		
25-18	296-25330-00	BRAKE SHOE COMP.	2		
25-19	90506-16034	SPRING, tension (102-25333-00)	2		
25-20	102-25355-01	LEVER, cam shaft	1		
25-21	90101-06278	BOLT, hexagon	1		
25-22	92901-06600	WASHER, plate	1		
25-23	92901-06100	WASHER, spring	1		
25-24	95301-06600	NUT, hexagon	1		
25-25	109-25428-20	GEAR, sprocket wheel (28T)	1		
25-26	101-25412-00	WASHER, lock	2		
25-27	90109-08319	BOLT (109-25411-00)	4		
25-28	90170-08158	NUT, hexagon	4		
25-29	439-25381-00	SHAFT, wheel	1		


Fig. 25 REAR WHEEL



REAR WHEEL

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
25-30	102-25389-00	PULLER, chain	2		
25-31	92901-06600	WASHER, plate	2		
25-32	92901-06100	WASHER, spring	2		
25-33	95301-06600	NUT, hexagon	2		
25-34	90387-12412	COLLAR (102-25383-00)	1		
25-35	90387-12096	COLLAR (109-25377-01)	1		
25-36	90171-12005	NUT, castle (367-25382-00)	1		
25-37	91401-30022	PIN, cotter	1		
25-38	94504-20088	CHAIN (DK420-88L)	1		
25-39	94604-20001	JOINT, chain (DK420)	1		
25-40	561-25371-00	BAR, tension	1		
25-41	90109-08183	BOLT, tension bar (102-25373-00)	1		
25-42	92901-08100	WASHER, spring	2		
25-43	95301-08700	NUT, hexagon	2		
25-44	91401-20012	PIN, cotter	1		
25-45	90468-12007	CLIP (102-25375-00)	1		
25-46	90109-08368	BOLT (183-25378-00)	1		


Fig. 26 HEAD LAMP · SPEEDOMETER



HEAD LAMP · SPEEDOMETER

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
26- 1	354-84130-00-26	BODY ASS'Y	1		Competition Yellow
	354-84130-00-29	BODY ASS'Y	1		Candy Blue
	354-84130-00-98	BODY ASS'Y	1		Frosting Black
	354-84130-00-E1	BODY ASS'Y	1		Chappy Red
26- 2	150-84153-00	. GROMMET	2		
26- 3	541-84103-40	HEAD LAMP UNIT ASS'Y	1		
26- 4	290-84115-21	. RIM, head lamp	1		
26- 5	260-84120-40	. LENS ASS'Y	1		
26- 6	290-84124-21	. SPRING, set	3		
26- 7	290-84114-21	. BULB, head lamp (6V-25/25W)	1		*
26- 8	541-84112-40	. SOCKET CORD ASS'Y	1		
26- 9	308-84135-21	. SPRING, set	1		
26-10	260-84146-40	. BULB (6V-4W)	1		
26-11	306-84346-40	. SOCKET CORD ASS'Y	1		
26-12	195-84325-00	SCREW, rim fitting	1		
26-13	97303-08020	BOLT, hexagon	2		
26-14	92903-08200	WASHER, plain	2		
26-15	92901-08100	WASHER, spring	2		
26-16	95301-08600	NUT	2		
26-17	1F2-83510-10	SPEEDOMETER ASS'Y	1		Km/h
26-18	122-83516-11	. BULB (6V-3.4W)	3		
26-19	563-83520-50	. SOCKET CORD ASS'Y	1		
26-20	355-83513-00	DAMPER	1		
26-21	439-83519-00-33	BRACKET, speedometer	1		Yamaha Black
26-22	355-83522-00	COLLAR	2		
26-23	355-83526-00	DAMPER	2		
26-24	355-83524-00	WASHER, plain	2		
26-25	92901-06100	WASHER, spring	4		
26-26	95301-06600	NUT, hexagon	4		
26-27	439-83550-00	SPEEDOMETER CABLE ASS'Y	1		


Fig. 27 CARRIER · TAIL LAMP



CARRIER · TAIL LAMP

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
27- 1	511-24810-00	CARRIER ASS'Y	1		
27- 2	97301-06015	BOLT, hexagon	4		
27- 3	92901-06100	WASHER, spring	4		
27- 4	92901-06600	WASHER, plate	4		
27- 5	543-84510-40	TAIL LAMP UNIT ASS'Y	1		
27- 6	296-84511-00	. BASE, tail lamp	1		
27- 7	122-84514-00	. BULB, tail lamp (6V-10/3W)	1		
27- 8	296-84523-00	. GASKET, tail lens	1		
27- 9	543-84521-70	. LENS, tail lamp	1		
27-10	127-84524-30	. SCREW, lens fitting	2		
27-11	278-84718-40	. BUSHING	1		
27-12	97301-06012	BOLT, hexagon	2		
27-13	92901-06100	WASHER, spring	2		
27-14	90480-12013	GROMMET (152-84518-00)	1		
27-15	543-28189-00	PLATE, number support	1		
27-16	97301-06020	BOLT, hexagon	2		
27-17	92901-06600	WASHER, plate	2		
27-18	92901-06100	WASHER, spring	2		
27-19	95301-06600	NUT, hexagon	2		
27-20	449-85131-00	REFLECTOR	1		
27-21	92901-05100	WASHER, spring	1		
27-22	95301-05600	NUT, hexagon	1		
27-23	543-21611-00	FENDER	1		
27-24	97306-06016	BOLT, hexagon	2		
27-25	90201-06552	WASHER, plate	2		
27-26	90201-06067	WASHER, plate	2		
27-27	92901-06100	WASHER, spring	2		
27-28	95301-06600	NUT, hexagon	2		


Fig. 28 ELECTRICAL



ELECTRICAL

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
28- 1	120-82110-21	BATTERY ASS'Y	1	U.R.	5-330
	120-82110-30	BATTERY ASS'Y			
28- 2	90445-08247	PIPE (439-82112-00)	1		
28- 3	268-82122-00	SEAT, battery	1		
28- 4	122-82131-00	BAND, battery	1		
28- 5	353-82150-00	FUSE HOLDER ASS'Y	1		
28- 6	116-82151-00	FUSE (6V-10A)	1		
28- 7	353-81970-62	RECTIFIER ASS'Y	1		
28- 8	98501-05020	SCREW, panhead	1		
28- 9	92901-05600	WASHER, plate	1		
28-10	375-83350-30	FLASHER RELAY ASS'Y	1		
28-11	439-82310-40	IGNITION COIL ASS'Y	1		
28-12	92901-06100	WASHER, spring	2		
28-13	95301-06600	NUT, hexagon	2		
28-14	808-82370-10	PLUG CAP ASS'Y	1		
28-15	420-83371-41	HORN	1		
28-16	97301-06012	BOLT, hexagon	2		
28-17	92901-06100	WASHER, spring	2		
28-18	395-83373-00	LEAD, horn	1		
28-19	511-82508-20	MAIN SWITCH ASS'Y	1		
28-20	98501-05010	SCREW, panhead	2		
28-21	92901-05100	WASHER, spring	2		
28-22	341-82540-01	NEUTRAL SWITCH ASS'Y	1		
28-23	511-85370-00	RESISTOR ASS'Y	1		
28-24	441-82530-00	STOP SWITCH ASS'Y	1		
28-25	441-81980-60	DIODE ASS'Y	1		
28-26	1F2-82590-20	WIRE HARNESS ASS'Y	1		
28-27	542-85720-00	OIL LEVEL GAUGE ASS'Y	1		

Fig. 29 LEG SHIELD



LEG SHIELD

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
29- 1	439-00000-50	LEG SHIELD ASS'Y	1		
29- 2	439-28311-00	. LEG SHIELD	1		
29- 3	439-28335-00	. PLATE	1		
29- 4	90201-06062	. WASHER, plate (256-21615-00)	4		
29- 5	97301-06012	. BOLT, hexagon	1		
29- 6	92901-06100	. WASHER, spring	1		
29- 7	439-28356-00	. STAY 1	1		
29- 8	95301-06600	. NUT, hexagon	1		
29- 9	92501-06050	. SCREW, panhead	1		
29-10	90387-06461	. COLLAR	1		
29-11	439-28371-00	. DAMPER	2		

YAMAHA
PARTS