



YAMAHA

PARTS LIST

YAMAHA CHAPPY

MODEL LB80IIA ('75)
(TYPE 592)

FOR EUROPE

YAMAHA MOTOR CO., LTD.

COPY RIGHT: ALL RIGHTS RESERVED

NO PART OF THIS PUBLICATION MAY BE REPRODUCED WITHOUT PERMISSION.

YAMAHA

PARTS LIST

YAMAHA CHAPPY
MODEL LB80IIA('75)
(TYPE 592)
FOR EUROPE


FOREWORD

This Parts List relates to the parts in use for the YAMAHA CHAPPY LB80IA (For FRANCE Specifications). When you ordering replacement parts for the LB80IA, refer to this Parts List and write both part numbers and part names correctly.


1. Structure of Part No.

Yamaha parts are divided largely into two categories; general parts and standard parts, and each part No. has the following structure:

General Parts



Standard Parts



Note: Every standard No. begins with 9.

2. How to Use this Parts List

- (1) Except for steel balls (whose size is indicated in inches), the size of all parts is indicated in millimeters in the following manner.

Hose (rubber or vinyl) Inside diameter - length

O-ring Section area - inside diameter

Washer, shim, collar Inside diameter - outside diameter - thickness (length)

- (2) Parts, which are to be supplied in the form of assemblies, are listed with an indentation of one letter's space, and a dot (.) is put

against the name of each part. If any two different assemblies (e.g., right and left side components) consist of almost the same type components, these two assemblies are listed in two lines, and then the names of component parts are listed in the subsequent lines with an indention as mentioned earlier. The quantity of parts is given in the following manner; that is, in the case of parts being the same in type between the right and left, a total quantity of parts is given. On the other hand, if the right and left side parts are different in type, the quantity of part(s) on each side is given.

Example

Description	Q'ty
CARBURETOR ASS'Y, left	1
CARBURETOR ASS'Y, right	1
. JET, pilot	2
. NOZZLE, main	2
. . . .	
. LEVER, starter, left	1
. LEVER, starter, right	1

(3) Key to Symbols

U.R.	Use size (thickness) and/or number as required
U.N.	Use as many as you need
T	Number of teeth in a gear
V	Voltage for light bulbs
S	"S" type oil seal or "S" type circlip
SD	"SD" type oil seal
SO	"SO" type oil seal
SW	"SW" type oil seal
E	"E" type circlip
R	"R" type circlip
F/No.	Frame No. (Applicable machine No.)

- (4) The parts marked with "X" in your country column are exclusive for your country, therefore, you should place an order only those parts. Meanwhile, the other parts are common for all European countries, and then we do not mention the names of countries.
- (5) The parts marked with * in the remark column of this list are not supplied with by Yamaha, those have to be found locally.
- (6) Please be advised that we supply you with Head Lamp Unit Ass'y, without bulbs.
- (7) The right and left in relation to parts are determined on the basis of the rider facing toward the front.
- (8) This Parts List is based on the model in the production line on Mar., 20, 1975. Accordingly, if any modifications which have been made to parts will be announced in the Yamaha Parts News. It is advisable that according to the Yamaha Parts News, you will make necessary corrections to the Parts List on hand to keep it up-to dated.

CONTENTS

ENGINE

Fig. 1	Crankcase · Cylinder	1
Fig. 2	Crankcase Cover	3
Fig. 3	Crank · Piston	5
Fig. 4	Clutch	9
Fig. 5	Transmission	11
Fig. 6	Shifter	15
Fig. 7	Kick Starter	17
Fig. 8	Intake	19
Fig. 9	Carburetor	21
Fig. 10	Exhaust	25
Fig. 11	Oil Pump	27
Fig. 12	Flywheel Magneto	29

CHASSIS

Fig. 13	Frame	33
Fig. 14	Rear Arm · Rear Cushion · Chain Case	35
Fig. 15	Stand · Footrest	37
Fig. 16	Front Fender · Rear Fender	39
Fig. 17	Front Fork	41
Fig. 18	Steering	43
Fig. 19	Handle · Wire	45
Fig. 20	Fuel Tank	49
Fig. 21	Oil Tank	51
Fig. 22	Seat · Under Cover	53
Fig. 23	Front Wheel	55
Fig. 24	Rear Wheel	59
Fig. 25	Head Lamp · Speedometer	63


Fig. 26	Carrier - Tail Lamp		65
Fig. 27	Flasher Lamp		67
Fig. 28	Electrical		69

NUMERICAL INDEX

ENGINE




Fig. 1 CRANKCASE · CYLINDER



CRANKCASE · CYLINDER

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
1- 1	440-15111-01	CASE, crank left	1		
1- 2	440-15121-01	CASE, crank right	1		
1- 3	91810-05016	PIN, dowel (8.4-12-14)	2		
1- 4	92501-06050	SCREW, panhead	6		
1- 5	92501-06045	SCREW, panhead	2		
1- 6	92501-06035	SCREW, panhead	2		
1- 7	90116-06100	BOLT, stud (122-11361-00)	4		
1- 8	440-11351-00	GASKET, cylinder	1		
1- 9	440-11311-00	CYLINDER	1		
1-10	122-11181-00	GASKET, cylinder head	1		
1-11	440-11111-00	HEAD, cylinder	1		
1-12	92901-06200	WASHER, plain	4		
1-13	95301-06600	NUT	4		
1-14	90340-12005	PLUG, drain (132-15351-00) ...	1		
1-15	90430-12038	GASKET, drain plug (132-15353-00)	1		
1-16	296-15128-00	HOLDER, right	1		
1-17	92501-08010	SCREW, panhead	1		
1-18	94701-00039	PLUG, spark (B-6HS)	1		


Fig. 2 CRANKCASE COVER



CRANKCASE COVER

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
2- 1	439-15410-01	CRANK CASE COVER ASS'Y ..	1		
2- 2	91810-02015	PIN, dowel (6.4-10-14)	4		
2- 3	92501-06100	SCREW, panhead	1		
2- 4	92501-06045	SCREW, panhead	3		
2- 5	164-15415-00	COVER, generator	1		
2- 6	98501-04005	SCREW, panhead	2		
2- 7	591-15435-00	EMBLEM, left cover	1		
2- 8	384-15421-01	COVER, crankcase right	1		
2- 9	296-15451-00	GASKET, crankcase cover	1		
2-10	92501-06025	SCREW, panhead	6		
2-11	92501-06040	SCREW, panhead	1		
2-12	439-15363-00	PLUG, oil	1		
2-13	439-15378-00	HOLDER	1		
2-14	592-15361-00	GAUGE, level	1		


Fig. 3 CRANK · PISTON



CRANK · PISTON

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
3- 1	386-11400-00	CRANK ASS'Y	1		
3- 2	298-11412-02	. CRANK, left	1		
3- 3	386-11422-00	. CRANK, right	1		
3- 4	126-11651-00	. ROD, connecting	1		
3- 5	93310-41810	. BEARING, big end	1		
3- 6	257-11681-00	. PIN, crank	1		
3- 7	93310-11202	BEARING, small end	1		
3- 8	367-11631-01-96	PISTON (39.96mm STD)	} U.R		
	367-11631-01-98	PISTON (39.98mm STD)		1	
	367-11635-01	PISTON (40.25mm 1st O.S)	1		Alternate Parts
	367-11636-01	PISTON (40.50mm 2nd O.S)	1		Alternate Parts
	367-11637-01	PISTON (40.75mm 3rd O.S)	1		Alternate Parts
	267-11638-01	PISTON (41.00mm 4th O.S)	1		Alternate Parts
3- 9	122-11633-00	PIN, piston	1		
3-10	93450-13022	CLIP (132-11634-00)	2		
3-11	367-11610-00	PISTON RING SET (STD)	1s		
	367-11610-10	PISTON RING SET (1st O.S) ...	1s		Alternate Parts
	367-11610-20	PISTON RING SET (2nd O.S) ...	1s		Alternate Parts
	367-11610-30	PISTON RING SET (3rd O.S) ...	1s		Alternate Parts
	367-11610-40	PISTON RING SET (4th O.S) ...	1s		Alternate Parts
3-12	93306-20418	BEARING (B6204CS)	2		
3-13	93102-20009	OIL SEAL (SD-20-35-7)	1		
3-14	90201-12178	WASHER, plate (214-11557-01)	1		
3-15	92901-12100	WASHER, spring	1		
3-16	90170-12175	NUT, hexagon	1		
3-17	90280-03017	KEY, woodruff (146-11545-00)	1		
3-18	93103-28011	OIL SEAL (SW-28-40-8)	1		
3-19	90387-20345	COLLAR, distance (132-16136-01)	1		
3-20	93210-18023	O-RING (1.2-17.6)	1		

Fig. 3 CRANK · PISTON



CRANK · PISTON

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
----------	-----------	-------------	------	---------------------------	---------

3-21	296-13178-02	GEAR, drive	1		
------	--------------	-------------------	---	--	--

3-22	93603-08072	PIN, dowel (2.5-7.8)	1		
------	-------------	----------------------------	---	--	--

ALTERNATE PARTS

3-23	367-11630-00	PISTON ASS'Y (STD)	1s		
------	--------------	--------------------------	----	--	--

	367-11630-10	PISTON ASS'Y (1st O.S)	1s		
--	--------------	------------------------------	----	--	--


	367-11630-20	PISTON ASS'Y (2nd O.S)	1s		
--	--------------	------------------------------	----	--	--

	367-11630-30	PISTON ASS'Y (3rd O.S)	1s		
--	--------------	------------------------------	----	--	--

	367-11630-40	PISTON ASS'Y (4th O.S)	1s		
--	--------------	------------------------------	----	--	--

Ref. No.
8, 9, 10, 11


Fig. 4 CLUTCH



CLUTCH

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
4- 1	384-16110-00	PRIMARY GEAR ASS'Y	 1		
4- 2	90201-16383	WASHER, plate	 1		
4- 3	90560-15119	SPACER (384-16181-00)	 1		
4- 4	90201-16250	WASHER, plate (384-16113-00)	1		
4- 5	384-16620-02	CLUTCH CARRIER ASS'Y	 1		
4- 6	90506-12025	. SPRING, tension (384-16626-00)	1		
4- 7	90560-15120	SPACER (384-16182-01)	 1		
4- 8	384-16630-02	CLUTCH CARRIER ASS'Y 2	... 1		
4- 9	90506-12025	. SPRING, tension (384-16626-00)	1		
4-10	296-16512-00	. BOSS, clutch housing	 1		
4-11	384-16586-01	. CAGE	 1		
4-12	93606-06091	. PIN, dowel (6-6)	 6		
4-13	90508-10225	. SPRING, tension (384-16539-01)	1		
4-14	93450-41030	. CIRCLIP (384-16529-00)	 1		
4-15	90201-13409	WASHER, plate	 1		
4-16	90208-13016	WASHER (384-16119-00)	 1		
4-17	90179-13073	NUT (384-16377-00)	 1		


Fig. 5 TRANSMISSION



TRANSMISSION

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
5- 1	384-17411-00	AXLE, main	1		
5- 2	90501-12089	SPRING (384-15572-00)	1		
5- 3	384-15631-00	GEAR, kick pinion (14T)	1		
5- 4	386-17121-00	GEAR, 2nd pinion (12T, 15T) ...	1		
5- 5	615-45533-01-03	SHIM (12.3-22-0.3)	} U.R. 1		
	615-45533-01-04	SHIM (12.3-22-0.4)			
	615-45533-01-05	SHIM (12.3-22-0.5)			
5- 6	93410-12003	CIRCLIP (S-12)	1		
5- 7	90338-17006	PLUG (296-17481-00)	1		
5- 8	93306-20303	BEARING (B6203Z)	1		
5- 9	296-17471-00	PLATE, bearing cover	1		
5-10	92501-06012	SCREW, panhead	2		
5-11	386-16170-00	DRIVEN GEAR COMP. 1	1		
5-12	90201-16383	WASHER, plate	1		
5-13	384-16180-00	BOSS ONE WAY COMP.	1		
5-14	384-15635-00	PAWL, one way	2		
5-15	384-15637-02	SPRING, pawl	1		
5-16	386-16150-00	PRIMARY DRIVEN GEAR COMP. 2 (59T)	1		
5-17	137-15654-00	HOLDER, kick gear	2		
5-18	93410-20009	CIRCLIP (S-20)	1		
5-19	439-17421-00	AXLE, drive	1		
5-20	384-17211-00	GEAR, 1st wheel (39T)	1		
5-21	386-17221-00	GEAR, 2nd wheel (29T)	1		
5-22	90387-25190	COLLAR, distance (384-17442-00) 1			
5-23	384-15651-00	GEAR, kick idle (22T, 39T)	1		
5-24	626-45577-00-01	WASHER (25.3-32-0.1)	} U.R. 1		
	626-45577-00-03	WASHER (25.3-32-0.3)			
	626-45577-00-05	WASHER (25.3-32-0.5)			
5-25	93440-25008	CIRCLIP (25φ)	1		


Fig. 5 TRANSMISSION



TRANSMISSION

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
5-26	90201-21381	WASHER	1		
5-27	90560-20040	SPACER (122-17429-00)	1		
5-28	93306-20401	BEARING (B6204)	1		
5-29	93102-26042	OIL SEAL (SD-26-38-5)	1		
5-30	90387-20491	COLLAR	1		
5-31	122-17461-30	SPROCKET, drive (13T)	} U.R 1		
	122-17461-40	SPROCKET, drive (14T)			
	122-17461-50	SPROCKET, drive (15T)			STD
5-32	90215-16020	WASHER, lock (102-17464-00)	1		
5-33	90179-16018	NUT, lock (102-17463-00)	1		


Fig. 6 SHIFTER



SHIFTER

Ref. No.	Parts No.	Description	Qty	Applicable Machine No.	Remarks
6- 1	384-18411-02	ROD, shift	1		
6- 2	90501-08183	SPRING, damper	1		
6- 3	234-18412-00	HEAD, shift	1		
6- 4	93430-04003	CIRCLIP (E-4)	1		
6- 5	384-18473-01	RETAINER, spring	1		
6- 6	90501-12198	SPRING, shift	1		
6- 7	90209-01134	WASHER	1		
6- 8	93420-15031	CIRCLIP (R-15)	1		
6- 9	93509-32012	BALL (9/32 inch)	8		
6-10	439-18451-01	LEVER, shift	1		
6-11	90206-10036	WASHER, wave	1		
6-12	93507-32009	BALL (7/32 inch)	1		
6-13	90501-09197	SPRING, boss stopper	1		
6-14	384-18428-00	SEAL, dust	1		
6-15	98501-05010	SCREW, panhead	4		
6-16	92901-05100	WASHER, spring	4		
6-17	439-18148-01	LEVER, stopper	1		
6-18	92901-06200	WASHER, plain	1		
6-19	90506-07066	SPRING (257-16345-00)	1		
6-20	132-16346-00	HOOK, spring	1		


Fig. 7 KICK STARTER



KICK STARTER

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
7- 1	296-15660-00	KICK AXLE ASS'Y	1		
7- 2	384-15641-00	GEAR, kick (27T)	1		
7- 3	90206-19027	WASHER, wave (296-15643-00)	2		
7- 4	296-15644-00	SHIM (19-26-1)	1		
7- 5	93410-19015	CIRCLIP (S-19)	2		
7- 6	296-15671-00	WHEEL, ratchet	1		
7- 7	90468-26046	CLIP (296-15687-00)	1		
7- 8	296-15664-00	GUIDE, kick spring	1		
7- 9	90508-26136	SPRING, torsion (304-15665-00)	1		
7-10	132-15676-00	COVER, kick spring	1		
7-11	93410-15005	CIRCLIP (S-15)	1		
7-12	93109-15001	OIL SEAL (SDO-15-26-6)	1		
7-13	439-15610-02-93	KICK CRANK ASS'Y	1		
7-14	122-15612-02	. LEVER, kick	1		
7-15	90504-18005	. SPRING (132-15625-01)	1		
7-16	90209-10108	. WASHER (132-15616-01)	1		
7-17	93440-10028	. CIRCLIP (132-15617-00)	1		
7-18	156-15618-01	COVER, kick lever	1		
7-19	97311-06025	BOLT	1		


Fig. 8 INTAKE



INTAKE

Ref. No.	Parts No.	Description	Qty	Applicable Machine No.	Remarks
8- 1	439-14411-00	CASE, air cleaner	1		
8- 2	439-14451-00	ELEMENT, air cleaner	1		
8- 3	439-14412-00	CAP, cleaner case	1		
8- 4	92501-06008	SCREW, panhead	2		
8- 5	92901-06100	WASHER, spring	2		
8- 6	91101-06010	BOLT	1		
8- 7	92901-06100	WASHER, spring	1		
8- 8	90506-06075	BAND (367-14455-01)	1		
8- 9	439-14453-00	JOINT, air cleaner	1		
8-10	90467-20023	CLIP (296-14455-00)	1		
8-11	439-13565-02	JOINT	1		
8-12	353-13621-00	PACKING, valve seat	2		
8-13	353-13610-01	REED VALVE ASS'Y	1		
8-14	314-13613-00	. VALVE, reed	1		
8-15	314-13616-01	. STOPPER, reed valve	1		
8-16	98512-03008	. SCREW, panhead	2		
8-17	92901-03100	. WASHER, spring	2		
8-18	92501-06025	SCREW, panhead	4		
8-19	92901-06100	WASHER, spring	4		


Fig. 9 CARBURETOR



CARBURETOR

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
9- 1	592-14101-00	CARBURETOR ASS'Y	1		
9- 2	127-14141-16	. NOZZLE, main (E-6)	1		
9- 3	127-14143-12	. JET, main (#60)	} U.R 1		STD
	127-14143-13	. JET, main (#65)			
	127-14143-14	. JET, main (#70)			
9- 4	193-14142-15	. JET, pilot (#15.0)	1		
9- 5	116-14190-12	. VALVE SEAT ASS'Y	1		
9- 6	127-14195-00	. WASHER, valve seat	1		
9- 7	439-14185-00	. FLOAT	1		
9- 8	439-14186-00	. PIN, float	1		
9- 9	439-14184-00	. GASKET, float chamber	1		
9-10	439-14181-00	. BODY, float chamber	1		
9-11	98503-04015	. SCREW, panhead	3		
9-12	92901-04100	. WASHER, spring	3		
9-13	439-14112-20	. VALVE, throttle	1		
9-14	127-14116-09	. NEEDLE (3G9-3)	1		
9-15	127-14137-00	. CLIP	1		
9-16	439-14136-00	. SEAT, spring	1		
9-17	439-14131-00	. SPRING, throttle	1		
9-18	439-14198-00	. GASKET, mixing chamber	1		
9-19	439-14158-00	. TOP, mixing chamber	1		
9-20	92901-04100	. WASHER, spring	4		
9-21	98501-04010	. SCREW, panhead	4		
9-22	127-14123-00	. SCREW, air adjusting	1		
9-23	127-14134-00	. SPRING, air adjusting	1		
9-24	98302-03012	. SCREW, throttle adjusting	1		
9-25	620-14133-00	. SPRING, throttle adjusting	1		
9-26	127-14171-00	. PLUNGER, starter	1		
9-27	127-14135-00	. SPRING, plunger	1		


Fig. 9 CARBURETOR



CARBURETOR

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
9-28	439-14174-01	. CAP, plunger	1		
9-29	437-14155-00	. GUIDE, cable	1		
9-30	127-14161-00	. NUT, wire adjusting	1		
9-31	432-14124-00	. SCREW, wire adjusting	1		
9-32	439-14169-00	. CAP	1		
9-33	439-14125-00	. SCREW, clip	1		
9-34	440-14197-00	PIPE, air vent	1		
9-35	353-14196-00	PIPE, over flow (3.0-150)	1		


Fig. 10 EXHAUST



EXHAUST

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
10- 1	592-14710-00	MUFFLER ASS'Y	1		
10- 2	132-14714-01	GASKET, muffler joint	1		
10- 3	395-14713-00	NUT, muffler joint	1		
10- 4	439-14611-02	PIPE, exhaust	1		
10- 5	122-14612-02	NUT, ring	1		
10- 6	132-14613-00	GASKET, exhaust pipe	1		
10- 7	97321-08018	BOLT, hexagon	1		
10- 8	92901-08200	WASHER, plain	1		
10- 9	439-14718-01	PROTECTOR, muffler	1		
10-10	91903-06010	SCREW, bind	3		
10-11	90202-06010	WASHER (178-14766-00)	6		
10-12	439-14729-00	EMBLEM, protector	1		
10-13	90202-04003	WASHER, plate (174-28316-00)	2		
10-14	90183-04005	NUT (116-28317-01)	2		


Fig. 11 OIL PUMP



OIL PUMP

Ref. No.	Parts No.	Description	Qty	Applicable Machine No.	Remarks
11- 1	440-13101-00	OIL PUMP ASS'Y	1		
11- 2	93210-26240	. O-RING (2.4-25.8)	1		
11- 3	93101-10001	. OIL SEAL (S-10-21-5)	1		
11- 4	296-13124-00	. GEAR, worm wheel (56T) ...	1		
11- 5	93430-07012	. CIRCLIP (E-7)	1		
11- 6	93603-14026	. PIN, dowel (3-14)	1		
11- 7	98901-04008	. SCREW, bind	1		
11- 8	90430-04004	. GASKET (137-13187-00)	1		
11- 9	296-13147-00	. SHIM	1		
11-10	384-13138-00	. PLATE, adjusting	1		
11-11	90170-10105	. NUT, hexagon	1		
11-12	384-13118-00	. BOLT, adjusting	1		
11-13	98501-05020	SCREW, panhead	1		
11-14	98501-05035	SCREW, panhead	1		
11-15	439-15416-02	COVER, oil pump 1	1		
11-16	92501-06015	SCREW, panhead	1		
11-17	92201-06012	SCREW, flathead	1		
11-18	439-15426-02	COVER, oil pump 2	1		
11-19	92501-06015	SCREW, panhead	2		
11-20	90480-11057	GROMMET	1		
11-21	90445-05206	HOSE	1		
11-22	384-13174-00	HOLDER, oil pipe	1		
11-23	90480-16179	GROMMET	1		

Fig. 12 FLYWHEEL MAGNETO




FLYWHEEL MAGNETO

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
12- 1	592-81300-20	FLYWHEEL MAGNETO ASS'Y	1		
12- 2	511-81350-20	. ROTOR ASS'Y	1		
12- 3	511-81312-20	. COIL, source	1		
12- 4	511-81313-20	. COIL, lighting	1		
12- 5	110-81348-21	. SCREW, panhead	4		
12- 6	437-81321-20	. CONTACT BREAKER ASS'Y	1		
12- 7	110-81346-21	. SCREW, panhead (4-10)	2		
12- 8	511-81325-20	. CONDENSER	1		
12- 9	116-81331-20	. LUBRICATOR	1		
12-10	104-81328-20	. CLAMP, lead	1		
12-11	110-81345-21	. SCREW, panhead	1		
12-12	592-81315-20	. LEAD WIRE ASS'Y	1		
12-13	98701-05015	SCREW, flathead	2		

CHASSIS




Fig.13 FRAME



FRAME

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
13- 1	551-21110-00-26	FRAME COMP.	1		Competition Yellow
	551-21110-00-29	FRAME COMP.	1		Candy Blue
	551-21110-00-98	FRAME COMP.	1		Frosting Black
	551-21110-00-E1	FRAME COMP.	1		Chappy Red
13- 2	439-21421-00-33	STAY, engine	1		Yamaha Black
13- 3	90109-08386	BOLT, hexagon	1		
13- 4	90170-08158	NUT, hexagon	1		
13- 5	92901-08100	WASHER, spring	3		
13- 6	95821-08120	BOLT, flange	1		
13- 7	90105-08025	BOLT	1		
13- 8	367-28100-10	TOOL ASS'Y	1		
13- 9	95701-08100	NUT, flange	1		
13-10	439-28321-00	STAY, under cover	1		
13-11	95821-08015	BOLT, flange	2		
13-12	439-28385-00	COVER, under	1		
13-13	91103-06015	BOLT	2		
13-14	90201-06052	WASHER, plate (136-22316-00)	2		
13-15	90480-21038	GROMMET (296-15486-00)	1		
13-16	439-28386-00	COVER, front	1		
13-17	97301-06015	BOLT	1		
13-18	92901-06100	WASHER, spring	1		
13-19	92901-06600	WASHER, plate	1		
13-20	439-21171-00	BOX, tool	1		
13-21	439-24723-00	DAMPER, seat guide	2		
13-22	439-23319-00	HOLDER, wire	1		760/
13-23	91101-06015	BOLT, hexagon	1		
13-24	92901-06200	WASHER, plain	1		
13-25	134-23480-10	STEERING LOCK ASS'Y	1		


Fig. 14 REAR ARM · REAR CUSHION · CHAIN CASE



REAR ARM · REAR CUSHION · CHAIN CASE

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
14- 1	439-22110-01-33	REAR ARM COMP.	1		Yamaha Black
14- 2	102-22123-00	BUSHING, rear arm	2		
14- 3	353-22141-01	SHAFT, pivot	1		
14- 4	95301-10600	NUT	1		
14- 5	395-22151-00	SEAL, guard	1		
14- 6	220-22210-20	REAR CUSHION ASS'Y	2		
14- 7	90176-10013	NUT, cap	2		
14- 8	90201-10140	WASHER, plate (102-22243-00)	4		
14- 9	95304-12800	NUT, cap	2		
14-10	90201-12190	WASHER, plate (122-22243-00)	2		
14-11	439-22311-00-35	CHAIN CASE, half	1		Silver
14-12	98501-05008	SCREW, panhead	2		
14-13	92901-05100	WASHER, spring	2		


Fig. 15 STAND · FOOTREST



STAND · FOOTREST

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
15- 1	439-27111-02-33	STAND, main	1		
15- 2	439-27112-00	SHAFT, main stand	1		
15- 3	93430-12008	CIRCLIP (E-12)	1		
15- 4	102-27114-00	STOPPER, main stand	1		
15- 5	439-27411-00	FOOTREST	1		
15- 6	384-27413-00	COVER, footrest	2		
15- 7	97201-08015	BOLT	1		
15- 8	92901-08100	WASHER, spring	1		
15- 9	90506-28100	SPRING (276-27316-00)	1		


Fig. 16 FRONT FENDER · REAR FENDER



FRONT FENDER · REAR FENDER

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
16- 1	439-21511-00	FENDER, front	1		
16- 2	97301-06015	BOLT, hexagon	4		
16- 3	92901-06100	WASHER, spring	4		
16- 4	92901-06600	WASHER, plate	4		
16- 5	439-21611-00	FENDER, rear	1		
16- 6	97301-06015	BOLT, hexagon	2		
16- 7	92901-06100	WASHER, spring	2		
16- 8	90201-06067	WASHER, plate (116-28324-00)	2		


Fig. 17 FRONT FORK



FRONT FORK

Ref. No.	Parts No.	Description	Qty	Applicable Machine No.	Remarks
17- 1	511-23101- E1 ^{E1}	FRONT FORK ASS'Y	1		7607/
17- 2	439-23126-00-35	. TUBE, outer left	1		Silver
17- 3	439-23136-00-35	. TUBE, outer right	1		Silver
17- 4	207-23147-00	. O-RING	2		
17- 5	367-23141-60	. SPRING, fork	1		
17- 6	290-23149-00	. WASHER	1		
17- 7	367-23166-60	. SPACER	1		
17- 8	439-23124-00	. TUBE, inner left	1		
17- 9	439-23134-00	. TUBE, inner right	1		
17-10	109-23125-00	. METAL, slide	2		
17-11	290-23150-01	. OUTER NUT COMP.	2		
17-12	109-23145-01	. . OIL SEAL	2		
17-13	290-23144-00	. SEAL, dust	2		
17-14	122-23163-00	. PACKING	2		
17-15	354-23115-90	. COVER, guide	2		
17-16	307-23114-00	. O-RING	2		
17-17	207-23112-00	. WASHER, cap	2		
17-18	395-23111-00	. BOLT, cap	2		
17-19	511-23340- E1 ^{E1} -33	. UNDER BRACKET COMP.	1		Yamaha Black 7607/
17-20	122-23346-01	. BOLT	1		
17-21	439-23121-00-26	COVER, upper left	1		Competition Yellow
	439-23121-00-29	COVER, upper left	1		Candy Blue
	439-23121-00-98	COVER, upper left	1		Frosting Black
	439-23121-00-E1	COVER, upper left	1		Chappy Red
17-22	439-23131-00-26	COVER, upper right	1		Competition Yellow
	439-23131-00-29	COVER, upper right	1		Candy Blue
	439-23131-00-98	COVER, upper right	1		Frosting Black
	439-23131-00-E1	COVER, upper right	1		Chappy Red


Fig. 18 STEERING



STEERING

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
18- 1	164-23462-00	SEAL, dust	1		
18- 2	156-23411-00	RACE, ball 1	1		
18- 3	156-23412-00	RACE, ball 2	1		
18- 4	93501-04011	BALL (1/4 inch)	19		
18- 5	122-23412-00	RACE, ball 2	1		
18- 6	122-23411-00	RACE, ball 1	1		
18- 7	93503-16010	BALL (3/16 inch)	22		
18- 8	122-23416-00	COVER, ball race	1		
18- 9	90179-25051	NUT (122-23453-00)	1		
18-10	439-23435-01	CROWN, handle	1		
18-11	90209-10021	WASHER (122-23443-00)	1		
18-12	90105-10006	BOLT (122-23451-00)	1		
18-13	122-23441-00	HOLDER, handle upper	2		
18-14	462-23442-00	HOLDER, handle under	2		
18-15	95301-10600	NUT, hexagon	2		
18-16	92901-10100	WASHER, spring	2		
18-17	91214-06035	BOLT	4		
18-18	92901-06600	WASHER, plate	4		

Fig. 19 HANDLE · WIRE



HANDLE · WIRE

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
19- 1	439-26111-00	HANDLE	1		
19- 2	395-26241-00	GRIP, left	1		
19- 3	439-82710-91	LEVER HOLDER ASS'Y, left ...	1		
19- 4	425-83912-00	. LEVER, left	1		
19- 5	98501-05025	. SCREW, panhead	1		
19- 6	395-83913-00	. COLLAR, lever	1		
19- 7	95301-05600	. NUT	1		
19- 8	439-83941-01	LEVER, starter	1		
19- 9	90209-10131	WASHER	1		
19-10	92901-06200	WASHER, plain	1		
19-11	91103-06008	BOLT	1		
19-12	395-83980-00	FRONT STOP SWITCH ASS'Y ..	2		
19-13	395-82920-92	LEVER HOLDER ASS'Y, right ..	1		
19-14	395-83922-01	. LEVER, right	1		
19-15	98501-05025	. SCREW, panhead	1		
19-16	395-83913-00	. COLLAR, lever	1		
19-17	95301-05600	. NUT	1		
19-18	395-26243-00	TUBE, guide	1		
19-19	150-26249-00	RING, leaf	1		
19-20	395-26242-00	GRIP, right	1		
19-21	439-26311-00	WIRE, throttle 1 (480mm)	1		
19-22	95301-10700	NUT, hexagon	1		
19-23	137-26261-01	CYLINDER, wire	1		
19-24	97301-06015	BOLT, hexagon	1		
19-25	92901-06100	WASHER, spring	1		
19-26	92901-06200	WASHER, plain	1		
19-27	439-26321-00	WIRE, pump (140mm)	1		
19-28	439-26312-00	WIRE, throttle 2 (160mm)	1		
19-29	439-26341-00	WIRE, brake front (965mm) ...	1		


HANDLE · WIRE

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
19-30	90123-08013	BOLT (156-26346-00)	1		
19-31	395-26323-00	NUT, adjusting	2		
19-32	90123-06011	BOLT (109-26345-00)	1		
19-33	90179-06143	NUT (109-26344-00)	1		
19-34	439-26351-00	WIRE, brake rear	1		
19-35	90501-10245	SPRING (180-27236-00)	1		
19-36	90249-12008	PIN (156-27237-00)	1		
19-37	90179-06176	NUT	1		
19-38	439-26331-00	WIRE, starter	1		
19-39	341-82594-00	CLAMP, wire harness	1		
19-40	90338-07011	PLUG (116-83931-00)	1		
19-41	257-26290-20	BACK MIRROR ASS'Y, left ...	1		

OPTIONAL PARTS

19-42	257-26290-70	BACK MIRROR ASS'Y, right	1		
-------	--------------	--------------------------	---	--	--


Fig. 20 FUEL TANK



FUEL TANK

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
20- 1	439-24111-01	TANK, fuel	1		
20- 2	439-24611-00	BODY, cap	1		
20- 3	439-24615-00	GASKET, plate 1	1		
20- 4	90430-02073	GASKET (439-24616-00)	1		
20- 5	439-24311-00	PIPE, fuel	1		
20- 6	168-24311-00	PIPE, fuel	1		
20- 7	90467-08003	CLIP (101-24356-00)	6		
20- 8	439-24500-00	FUEL COCK ASS'Y	1		
20- 9	266-24523-00	. PACKING	1		
20-10	439-24525-00	. PLATE	1		
20-11	98503-03006	. SCREW, panhead	2		
20-12	439-24524-00	. LEVER	1		
20-13	266-24522-00	. PACKING	1		
20-14	395-24521-00	. CUP, filter	1		
20-15	98501-06015	SCREW, panhead	2		
20-16	92901-06100	WASHER, spring	2		
20-17	90445-09106	HOSE (174-21766-00 5-330) ...	1		
20-18	439-24317-00	PIPE 7	1		
20-19	439-24182-00	DAMPER, locating 2	2		


Fig. 21 OIL TANK



OIL TANK

Ref. No.	Parts No.	Description	Qty	Applicable Machine No.	Remarks
21- 1	439-21751-00	TANK, oil	1		
21- 2	296-21771-01	BODY, cap	1		
21- 3	296-21772-00	GASKET, cap	1		
21- 4	90445-09256	HOSE (5-380)	1		
21- 5	90467-08003	CLIP (101-24356-00)	2		
21- 6	90446-09012	HOSE (248-21745-00 5-390) ...	1		
21- 7	90504-05014	SPRING, compression	1		
21- 8	439-24181-00	DAMPER, locating 1	2		
21- 9	439-24173-00	BAND, tank fitting	1		
21-10	439-21778-00	DAMPER, locating	2		
21-11	439-21759-00	GROMMET	1		
21-12	439-24119-00	TUBE, connector	1		


Fig. 22 SEAT · UNDER COVER



SEAT · UNDER COVER

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
22- 1	439-24710-00	SINGLE SEAT ASS'Y	1		
22- 2	439-24711-00	. COVER, single seat	1		
22- 3	439-24726-00	HINGE, seat	1		
22- 4	91502-05085	PIN, clevis	1		
22- 5	90468-10050	CLIP (156-83525-00)	2		
22- 6	95301-06600	NUT, hexagon	5		
22- 7	92901-06100	WASHER, spring	5		
22- 8	439-24754-00	HOOK, seat	1		
22- 9	91501-06010	PIN, clevis	1		
22-10	296-24723-00	DAMPER, seat	2		
22-11	214-24724-00	DAMPER, seat	2		
22-12	395-28185-00	LID	1		
22-13	439-24796-00-26	COVER, seat under	1		Competition Yellow
	439-24796-00-29	COVER, seat under	1		Candy Blue
	439-24796-00-98	COVER, seat under	1		Frosting Black
	439-24796-00-E1	COVER, seat under	1		Chappy Red
22-14	439-21783-00	EMBLEM, cover	1		
22-15	439-21278-00	MOLD, cover	1		


Fig. 23 FRONT WHEEL



FRONT WHEEL

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
23- 1	439-25111-00	HUB, front	1		
23- 2	395-25337-00-35	PANEL, wheel 1	1		Silver
23- 3	395-25347-00-35	PANEL, wheel 2	1		Silver
23- 4	90101-08249	BOLT, hexagon	4		
23- 5	92901-08100	WASHER, spring	8		
23- 6	95301-08600	NUT, hexagon	8		
23- 7	97301-08015	BOLT, hexagon	4		
23- 8	92901-08600	WASHER, plain	4		
23- 9	94140-08138	TIRE (4.00-8-4PR)	1		
23-10	94240-08044	TUBE (4.00-8)	1		
23-11	195-25115-00	FLANGE, spacer	1		
23-12	90560-10104	SPACER (439-25117-00)	1		
23-13	93306-30003	BEARING (B6300Z)	2		
23-14	93106-20001	OIL SEAL (DD-20-35-7)	1		
23-15	93105-47007	OIL SEAL (SDD-47-58-7)	1		
23-16	93410-20009	CIRCLIP (S-20)	1		
23-17	90201-02269	WASHER, plate (183-25147-00)	2		
23-18	183-25149-00	CLUTCH, meter	1		
23-19	439-25135-00	GEAR, drive (26T)	1		
23-20	342-25121-00	PLATE, brake shoe	1		
23-21	296-25330-00	BRAKE SHOE COMP.	2		
23-22	122-25351-01	CAM SHAFT	1		
23-23	90506-16034	SPRING, tension (102-25333-00)	2		
23-24	109-25155-00	LEVER, camshaft	1		
23-25	90101-06278	BOLT, hexagon	1		
23-26	92901-06600	WASHER, plate	1		
23-27	92901-06100	WASHER, spring	1		
23-28	95301-06600	NUT, hexagon	1		
23-29	90201-07076	WASHER, plate (183-25146-00)	1		


Fig. 23 FRONT WHEEL



FRONT WHEEL

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
23-30	439-25138-00	GEAR, meter (15T)	1		
23-31	93210-14104	O-RING (2.4-13.8)	1		
23-32	109-25136-00	BUSHING	1		
23-33	93104-07003	OIL SEAL (SO-7-14-4)	1		
23-34	102-25137-00	RING, stop	1		
23-35	90387-10081	COLLAR (128-25183-00)	1		
23-36	439-25181-00	SHAFT, wheel	1		
23-37	90171-10004	NUT, castle (353-25182-00) ...	1		
23-38	91401-20020	PIN, cotter	1		


Fig. 24 REAR WHEEL



REAR WHEEL

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
24- 1	439-25311-00	HUB, rear	1		
24- 2	395-25337-00-35	PANEL, wheel 1	1		Silver
24- 3	395-25347-00-35	PANEL, wheel 2	1		Silver
24- 4	90101-08249	BOLT, hexagon	4		
24- 5	92901-08100	WASHER, spring	8		
24- 6	95301-08600	NUT, hexagon	8		
24- 7	97321-08015	BOLT, hexagon	4		
24- 8	92901-08600	WASHER, plain	4		
24- 9	94140-08138	TIRE (4.00-8-4PR)	1		
24-10	94240-08044	TUBE (4.00-8)	1		
24-11	109-25315-00	FLANGE, spacer	1		
24-12	90560-12110	SPACER (439-25317-00)	1		
24-13	93306-30103	BEARING (B6301Z)	2		
24-14	93104-21016	OIL SEAL (SO-21-37-7)	1		
24-15	93106-20002	OIL SEAL (DD-20-37-8)	1		
24-16	102-25321-00-38	PLATE, brake shoe	1		
24-17	122-25351-01	CAM SHAFT	1		
24-18	296-25330-00	BRAKE SHOE COMP.	2		
24-19	90506-16034	SPRING, tension (102-25333-00)	2		
24-20	102-25355-01	LEVER, camshaft	1		
24-21	90101-06278	BOLT, hexagon	1		
24-22	92901-06600	WASHER, plate	1		
24-23	92901-06100	WASHER, spring	1		
24-24	95301-06600	NUT, hexagon	1		
24-25	109-25432-10	GEAR, sprocket wheel (28T) ...	1		
24-26	101-25412-00	WASHER, lock	2		
24-27	90109-08319	BOLT (109-25411-00)	4		
24-28	90170-08158	NUT, hexagon	4		
24-29	439-25381-00	SHAFT, wheel	1		


Fig. 24 REAR WHEEL



REAR WHEEL

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
24-30	102-25389-00	PULLER, chain	2		
24-31	92901-06600	WASHER, plate	2		
24-32	92901-06100	WASHER, spring	2		
24-33	95301-06600	NUT, hexagon	2		
24-34	90387-12412	COLLAR (102-25383-00)	1		
24-35	90387-12096	COLLAR (109-25377-01)	1		
24-36	90171-12005	NUT, castle (367-25382-00) ...	1		
24-37	91401-30022	PIN, cotter	1		
24-38	94504-20089	CHAIN (DK420-89L)	1		
24-39	94604-20001	. JOINT, chain	1		
24-40	439-25371-00	BAR, tension	1		
24-41	90109-08183	BOLT (102-25373-00)	1		
24-42	92901-08100	WASHER, spring	1		
24-43	95301-08700	NUT, hexagon	2		
24-44	91401-20012	PIN, cotter	2		
24-45	92901-08600	WASHER, plate	1		
24-46	90468-12007	CLIP (102-25375-00)	1		


Fig. 25 HEAD LAMP · SPEEDOMETER



HEAD LAMP · SPEEDOMETER

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
25- 1	241-84330-00-26	BODY ASS'Y	1		Competition Yellow
	241-84330-00-29	BODY ASS'Y	1		Candy Blue
	241-84330-00-98	BODY ASS'Y	1		Frosting Black
	241-84330-00-E1	BODY ASS'Y	1		Chappy Red
25- 2	150-84153-00	. GROMMET	2		
25- 3	290-84103-21	HEAD LAMP UNIT ASS'Y	1		
25- 4	290-84115-21	. RIM, head lamp	1		
25- 5	290-84120-21	. LENS ASS'Y	1		
25- 6	290-84114-21	. BULB, head lamp (6V-25/25W)	1		*
25- 7	314-84112-20	. SOCKET	1		
25- 8	308-84135-21	. SPRING	1		
25- 9	260-84147-40	. BULB, pilot lamp (6V-4W) ...	1		*
25-10	306-84346-40	. SOCKET CORD ASS'Y	1		
25-11	290-84124-21	. SPRING, reflector set	3		
25-12	195-84325-00	SCREW, rim fitting	1		
25-13	439-83510-10	SPEEDOMETER ASS'Y	1		Km/h
25-14	122-83516-10	. BULB (6V-3W)	2		
25-15	439-83536-50	. SOCKET CORD ASS'Y	1		
25-16	355-83513-00	DAMPER	1		
25-17	439-83519-00-33	BRACKET, speedometer	1		Yamaha Black
25-18	355-83522-00	COLLAR	2		
25-19	355-83526-00	DAMPER	2		
25-20	355-83524-00	WASHER, special	4		
25-21	92901-06100	WASHER, spring	4		
25-22	95301-06600	NUT, hexagon	4		
25-23	439-83550-00	SPEEDOMETER CABLE ASS'Y	1		


Fig. 26 CARRIER · TAIL LAMP



CARRIER · TAIL LAMP

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
26- 1	511-24810-00	CARRIER ASS'Y	1		
26- 2	97301-06015	BOLT, hexagon	4		
26- 3	92901-06100	WASHER, spring	4		
26- 4	92901-06600	WASHER, plate	4		
26- 5	511-84510-20	TAIL LAMP UNIT ASS'Y	1		
26- 6	439-84511-00	. BASE, tail lamp	1		
26- 7	122-84514-00	. BULB, tail lamp (6V-10/3W)	1		
26- 8	296-84523-00	. GASKET, tail lens	1		
26- 9	511-84521-20	. LENS, tail lamp	1		
26-10	127-84524-30	. SCREW, lens fitting	2		
26-11	97301-06012	BOLT, hexagon	2		
26-12	92901-06100	WASHER, spring	2		
26-13	90480-12013	GROMMET (152-84518-00)	1		
26-14	550-28189-00	PLATE, number support	1		
26-15	97301-06020	BOLT, hexagon	2		
26-16	92901-06600	WASHER, plate	2		
26-17	92901-06100	WASHER, spring	2		
26-18	95301-06600	NUT, hexagon	2		
26-19	449-85131-00	REFLECTOR	1		
26-20	92901-05200	WASHER, plain	1		
26-21	92901-05100	WASHER, spring	1		
26-22	95301-05600	NUT, hexagon	1		
26-23	439-21308-00	HANGER, helmet	1		
26-24	92701-06030	SCREW, flathead	1		


Fig. 27 FLASHER LAMP



FLASHER LAMP

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
27- 1	260-83310-35-93	FRONT FLASHER LAMP ASS'Y	2		
27- 2	183-83332-21	. LENS, flasher	2		
27- 3	183-83313-70	. GASKET, flasher lens	2		
27- 4	185-83311-10	. BULB (6V-8W)	2		
27- 5	183-83333-21	. SCREW, lens fitting	4		
27- 6	439-83330-10-93	REAR FLASHER LAMP ASS'Y, left	1		
27- 7	439-83340-10-93	REAR FLASHER LAMP ASS'Y, right	1		
27- 8	183-83332-21	. LENS, flasher	2		
27- 9	183-83313-70	. GASKET, flasher lens	2		
27-10	185-83311-10	. BULB (6V-8W)	2		
27-11	183-83333-21	. SCREW, lens fitting	4		
27-12	92901-08100	WASHER, spring	2		
27-13	95301-08600	NUT, hexagon	2		

Fig. 28 ELECTRICAL



ELECTRICAL

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
28- 1	120-82110-21	BATTERY ASS'Y	1		
28- 2	90445-08247	HOSE (439-82112-00 5-330)	1		
28- 3	268-82122-00	SEAT, battery	1		
28- 4	122-82131-00	BAND, battery	1		
28- 5	353-82150-00	FUSE HOLDER ASS'Y	1		
28- 6	116-82151-00	. FUSE (6V-10A)	1		
28- 7	353-81970-62	RECTIFIER ASS'Y	1		
28- 8	98501-05020	SCREW, panhead	1		
28- 9	92901-05200	WASHER, plain	1		
28-10	439-83350-11	FLASHER RELAY ASS'Y	1		
28-11	439-82310-40	IGNITION COIL ASS'Y	1		
28-12	92901-06100	WASHER, spring	2		
28-13	95301-06600	NUT, hexagon	2		
28-14	808-82370-10	PLUG CAP ASS'Y	1		With Noise Suppressor
28-15	420-83371-41	HORN	1		
28-16	395-83373-00	LEAD, horn	1		
28-17	91201-06012	BOLT	2		
28-18	92901-06100	WASHER, spring	2		
28-19	511-83378-00	STAY, horn	1		
28-20	97301-06012	BOLT, hexagon	2		
28-21	92901-06100	WASHER, spring	2		
28-22	511-85370-00	RESISTOR ASS'Y	1		
28-23	511-82508-20	MAIN SWITCH ASS'Y	1		
28-24	98501-05010	SCREW, panhead	2		
28-25	92901-05100	WASHER, spring	2		
28-26	592-82590-20	WIRE HARNESS ASS'Y	1		
28-27	341-26397-01	BAND	1		

NUMERICAL INDEX



NUMERICAL INDEX

Ref No.	Parts No.	Ref No.	Parts No.	Ref No.	Parts No.
24-26	101-25412-00	3- 4	126-11651-00	23-11	195-25115-00
14- 2	102-22123-00	9-14	127-14116-09	25-12	195-84325-00
23-34	102-25137-00	9-22	127-14123-00	17-17	207-23112-00
24-16	102-25321-00-38	9-23	127-14134-00	17- 4	207-23147-00
24-20	102-25355-01	9-27	127-14135-00	22-11	214-24724-00
24-30	102-25389-00	9-15	127-14137-00	14- 6	220-22210-20
15- 4	102-27114-00	9- 2	127-14141-16	6- 3	234-18412-00
12-10	104-81328-20	9- 3	127-14143-12	25- 1	241-84330-00-E1
17-10	109-23125-00	9- 3	127-14143-13	25- 1	241-84330-00-26
17-12	109-23145-01	9- 3	127-14143-14	25- 1	241-84330-00-29
23-32	109-25136-00	9-30	127-14161-00	25- 1	241-84330-00-98
23-24	109-25155-00	9-26	127-14171-00	3- 6	257-11681-00
24-11	109-25315-00	9- 6	127-14195-00	19-41	257-26290-20
24-25	109-25432-10	26-10	127-84524-30	19-42	257-26290-70
12-11	110-81345-21	10- 6	132-14613-00	27- 1	260-83310-35-93
12- 7	110-81346-21	10- 2	132-14714-01	25- 9	260-84147-40
12- 5	110-81348-21	6-20	132-16346-00	20-13	266-24522-00
9- 5	116-14190-12	7-10	132-15676-00	20- 9	266-24523-00
12- 9	116-81331-20	13-25	134-23480-10	28- 3	268-82122-00
28- 6	116-82151-00	5-17	137-15654-00	17-13	290-23144-00
28- 1	120-82110-21	19-23	137-26261-01	17- 6	290-23149-00
1-10	122-11181-00	19-19	150-26249-00	17-11	290-23150-01
3- 9	122-11633-00	25- 2	150-84153-00	25- 3	290-84103-21
10- 5	122-14612-02	18- 2	156-23411-00	25- 6	290-84114-21
7-14	122-15612-02	18- 3	156-23412-00	25- 4	290-84115-21
5-31	122-17461-30	7-18	156-15618-01	25- 5	290-84120-21
5-31	122-17461-40	2- 5	164-15415-00	25-11	290-84124-21
5-31	122-17461-50	18- 1	164-23462-00	11- 4	296-13124-00
17-14	122-23163-00	20- 6	168-24311-00	11- 9	296-13147-00
17-20	122-23346-01	23-18	183-25149-00	3-21	296-13178-02
18- 6	122-23411-00	27- 3	183-83313-70	1-16	296-15128-00
18- 5	122-23412-00	27- 9	183-83313-70	2- 9	296-15451-00
18- 8	122-23416-00	27- 2	183-83332-21	7- 4	296-15644-00
18-13	122-23441-00	27- 8	183-83332-21	7- 1	296-15660-00
23-22	122-25351-01	27- 5	183-83333-21	7- 8	296-15664-00
24-17	122-25351-01	27-11	183-83333-21	7- 6	296-15671-00
28- 4	122-82131-00	27- 4	185-83311-10	4-10	296-16512-00
25-14	122-83516-10	27-10	185-83311-10	5- 9	296-17471-00
26- 7	122-84514-00	9- 4	193-14142-15	21- 2	296-21771-01

NUMERICAL INDEX

Ref No.	Parts No.	Ref No.	Parts No.	Ref No.	Parts No.
21- 3	296-21772-00	3- 8	367-11637-01	19- 2	395-26241-00
22-10	296-24723-00	3- 8	267-11638-01	19-20	395-26242-00
23-21	296-25330-00	17- 5	367-23141-60	19-18	395-26243-00
24-18	296-25330-00	17- 7	367-23166-60	19-31	395-26323-00
26- 8	296-84523-00	13-19	367-28100-10	22-12	395-28185-00
3- 2	298-11412-02	11-12	384-13118-00	19-13	395-82920-92
25-10	306-84346-40	11-10	384-13138-00	28-16	395-83373-00
17-16	307-23114-00	11-22	384-13174-00	19- 6	395-83913-00
25- 8	308-84135-21	2- 8	384-15421-01	19-16	395-83913-00
8-14	314-13613-00	5- 3	384-15631-00	19-14	395-83922-01
8-15	314-13616-01	5-14	384-15635-00	19-12	395-83980-00
25- 7	314-84112-20	5-15	384-15637-02	28-15	420-83371-41
28-27	341-26397-01	7- 2	384-15641-00	19- 4	425-83912-00
19-39	341-82594-00	5-23	384-15651-00	9-31	432-14124-00
23-20	342-25121-00	4- 1	384-16110-00	12- 6	437-81321-20
8-13	353-13610-01	5-13	384-16180-00	8-11	439-13565-02
8-12	353-13621-00	4-11	384-16586-01	9-13	439-14112-20
9-35	353-14196-00	4- 5	384-16620-02	9-33	439-14125-00
14- 3	353-22141-01	4- 8	384-16630-02	9-17	439-14131-00
28- 7	353-81970-62	5-20	384-17211-00	9-16	439-14136-00
28- 5	353-82150-00	5- 1	384-17411-00	9-29	437-14155-00
17-15	354-23115-90	6- 1	384-18411-02	9-19	439-14158-00
25-16	355-83513-00	6-14	384-18428-00	9-32	439-14169-00
25-18	355-83522-00	6- 5	384-18473-01	9-28	439-14174-01
25-20	355-83524-00	15- 6	384-27413-00	9-10	439-14181-00
25-19	355-83526-00	3- 1	386-11400-00	9- 9	439-14184-00
3-11	367-11610-00	3- 3	386-11422-00	9- 7	439-14185-00
3-11	367-11610-10	5-16	386-16150-00	9- 8	439-14186-00
3-11	367-11610-20	5-11	386-16170-00	9-18	439-14198-00
3-11	367-11610-30	5- 4	386-17121-00	8- 1	439-14411-00
3-11	367-11610-40	5-21	386-17221-00	8- 3	439-14412-00
3-23	367-11630-00	10- 3	395-14713-00	8- 2	439-14451-00
3-23	367-11630-10	14- 5	395-22151-00	8- 9	439-14453-00
3-23	367-11630-20	17-18	395-23111-00	10- 4	439-14611-02
3-23	367-11630-30	20-14	395-24521-00	10- 9	439-14718-01
3-23	367-11630-40	23- 2	395-25337-00-35	10-12	439-14729-00
3- 8	367-11631-01-96	24- 2	395-25337-00-35	2-12	439-15363-00
3- 8	367-11631-01-98	23- 3	395-25347-00-35	2-13	439-15378-00
3- 8	367-11635-01	24- 3	395-25347-00-35	2- 1	439-15410-01
3- 8	367-11636-01				

NUMERICAL INDEX

Ref No.	Parts No.	Ref No.	Parts No.	Ref No.	Parts No.
11-15	439-15416-02	20- 8	439-24500-00	25-13	439-83510-10
11-18	439-15426-02	20-12	439-24524-00	25-17	439-83519-00-33
7-13	439-15610-02-93	20-10	439-24525-00	25-15	439-83536-50
5-19	439-17421-00	20- 2	439-24611-00	25-23	439-83550-00
6-17	439-18148-01	20- 3	439-24615-00	19- 8	439-83941-01
6-10	439-18451-01	22- 1	439-24710-00	26- 6	439-84511-00
13-18	439-21171-00	22- 2	439-24711-00	1-11	440-11111-00
22-15	439-21278-00	13-21	439-24723-00	1- 9	440-11311-00
26-23	439-21308-00	22- 3	439-24726-00	1- 8	440-11351-00
13- 2	439-21421-00-33	22- 8	439-24754-00	11- 1	440-13101-00
16- 1	439-21511-00	22-13	439-24796-00-E1	9-34	440-14197-00
16- 5	439-21611-00	22-13	439-24796-00-26	1- 1	440-15111-01
21- 1	439-21751-00	22-13	439-24796-00-29	1- 2	440-15121-01
21-11	439-21759-00	22-13	439-24796-00-98	26-19	449-85131-00
21-10	439-21778-00	23- 1	439-25111-00	18-14	462-23442-00
22-14	439-21783-00	23-19	439-25135-00	17- 1	511-23101-F0
14- 1	439-22110-01-33	23-30	439-25138-00	17-19	511-23340-F0-33
14-11	439-22311-00-35	23-36	439-25181-00	26- 1	511-24810-00
17-21	439-23121-00-E1	24- 1	439-25311-00	12- 3	511-81312-20
17-21	439-23121-00-26	24-40	439-25371-00	12- 4	511-81313-20
17-21	439-23121-00-29	24-29	439-25381-00	12- 8	511-81325-20
17-21	439-23121-00-98	19- 1	439-26111-00	12- 2	511-81350-20
17- 8	439-23124-00	19-21	439-26311-00	28-23	511-82508-20
17- 2	439-23126-00-35	19-28	439-26312-00	28-19	511-83378-00
17-22	439-23131-00-E1	19-27	439-26321-00	26- 5	511-84510-20
17-22	439-23131-00-26	19-38	439-26331-00	26- 9	511-84521-20
17-22	439-23131-00-29	19-29	439-26341-00	28-22	511-85370-00
17-22	439-23131-00-98	19-34	439-26351-00	26-14	550-28189-00
17- 9	439-23134-00	15- 1	439-27111-02-33	13- 1	551-21110-00-E1
17- 3	439-23136-00-35	15- 2	439-27112-00	13- 1	551-21110-00-26
13-22	439-23319-00	15- 5	439-27411-00	13- 1	551-21110-00-29
18-10	439-23435-01	13- 8	439-28321-00	13- 1	551-21110-00-98
20- 1	439-24111-01	13-10	439-28385-00	2- 7	591-15435-00
21-12	439-24119-00	13-14	439-28386-00	9- 1	592-14101-00
21- 9	439-24173-00	28-11	439-82310-40	10- 1	592-14710-00
21- 8	439-24181-00	19- 3	439-82710-91	2-14	592-15361-00
20-19	439-24182-00	27- 6	439-83330-10-93	12- 1	592-81300-20
20- 5	439-24311-00	27- 7	439-83340-10-93	12-12	592-81315-20
20-18	439-24317-00	28-10	439-83350-11	28-26	592-82590-20

NUMERICAL INDEX

Ref No.	Parts No.	Ref No.	Parts No.	Ref No.	Parts No.
5- 5	615-45533-01-03	14-10	90201-12190	24-46	90468-12007
5- 5	615-45533-01-04	4- 4	90201-16250	7- 7	90468-26046
5- 5	615-45533-01-05	4- 2	90201-16383	11-20	90480-11057
9-25	620-14133-00	4-15	90201-13409	26-13	90480-12013
5-24	626-45577-00-01	5-12	90201-16383	11-23	90480-16179
5-24	626-45577-00-03	5-26	90201-21381	13-13	90480-21038
5-24	626-45577-00-05	10-13	90202-04003	6- 2	90501-08183
28-14	808-82370-10	10-11	90202-06010	6-13	90501-09197
23-25	90101-06278	6-11	90206-10036	19-35	90501-10245
24-21	90101-06278	7- 3	90206-19027	5- 2	90501-12089
23- 4	90101-08249	4-16	90208-13016	6- 6	90501-12198
24- 4	90101-08249	6- 7	90209-01134	21- 7	90504-05014
13- 7	90105-08025	18-11	90209-10021	7-15	90504-18005
18-12	90105-10006	7-16	90209-10108	8- 8	90506-06075
24-41	90109-08183	19- 9	90209-10131	6-19	90506-07066
24-27	90109-08319	5-32	90215-16020	4- 6	90506-12025
13- 3	90109-08386	19-36	90249-12008	4- 9	90506-12025
1- 7	90116-06100	3-17	90280-03017	23-23	90506-16034
19-32	90123-06011	19-40	90338-07011	24-19	90506-16034
19-30	90123-08013	5- 7	90338-17006	15- 9	90506-28100
13- 4	90170-08158	23-35	90387-10081	4-13	90508-10225
24-28	90170-08158	24-35	90387-12096	7- 9	90508-26136
11-11	90170-10105	24-34	90387-12412	23-12	90560-10104
3-16	90170-12175	3-19	90387-20345	24-12	90560-12110
23-37	90171-10004	5-30	90387-20491	4- 3	90560-15119
24-36	90171-12005	5-22	90387-25190	4- 7	90560-15120
14- 7	90176-10013	1-14	90340-12005	5-27	90560-20040
19-33	90179-06143	20- 4	90430-02073	8- 6	91101-06010
19-37	90179-06176	11- 8	90430-04004	13-23	91101-06015
4-17	90179-13073	1-15	90430-12038	19-11	91103-06008
5-33	90179-16018	11-21	90445-05206	13-11	91103-06015
18- 9	90179-25051	28- 2	90445-08247	28-17	91201-06012
10-14	90183-04005	20-17	90445-09106	18-17	91214-06035
23-17	90201-02269	21- 4	90445-09256	24-44	91401-20012
13-12	90201-06052	21- 6	90446-09012	23-38	91401-20020
16- 8	90201-06067	20- 7	90467-08003	24-37	91401-30022
23-29	90201-07076	21- 5	90467-08003	22- 9	91501-06010
14- 8	90201-10140	8-10	90467-20023	22- 4	91502-05085
3-14	90201-12178	22- 5	90468-10050	2- 2	91810-02015

NUMERICAL INDEX

Ref No.	Parts No.	Ref No.	Parts No.	Ref No.	Parts No.
1- 3	91810-05016	26- 3	92901-06100	24-15	93106-20002
10-10	91903-06010	26-12	92901-06100	7-12	93109-15001
11-17	92201-06012	26-17	92901-06100	23-31	93210-14104
8- 4	92501-06008	28-12	92901-06100	3-20	93210-18023
5-10	92501-06012	28-18	92901-06100	11- 2	93210-26240
11-16	92501-06015	28-21	92901-06100	5- 8	93306-20303
11-19	92501-06015	1-12	92901-06200	5-28	93306-20401
2-10	92501-06025	6-18	92901-06200	3-12	93306-20418
8-18	92501-06025	13-24	92901-06200	24-13	93306-30103
1- 6	92501-06035	19-10	92901-06200	23-13	93306-30003
2-11	92501-06040	19-26	92901-06200	3- 7	93310-11202
1- 5	92501-06045	13-17	92901-06600	5- 6	93410-12003
2- 4	92501-06045	16- 4	92901-06600	7-11	93410-15005
1- 4	92501-06050	18-18	92901-06600	3- 5	93310-41810
2- 3	92501-06100	23-26	92901-06600	7- 5	93410-19015
1-17	92501-08010	24-22	92901-06600	5-18	93410-20009
26-24	92701-06030	24-31	92901-06600	23-16	93410-20009
8-17	92901-03100	26- 4	92901-06600	6- 8	93420-15031
9-12	92901-04100	26-16	92901-06600	6- 4	93430-04003
9-20	92901-04100	13- 5	92901-08100	11- 5	93430-07012
6-16	92901-05100	15- 8	92901-08100	15- 3	93430-12008
14-13	92901-05100	23- 5	92901-08100	7-17	93440-10028
26-21	92901-05100	24- 5	92901-08100	5-25	93440-25008
28-25	92901-05100	24-42	92901-08100	3-10	93450-13022
26-20	92901-05200	27-12	92901-08100	4-14	93450-41030
28- 9	92901-05200	10- 8	92901-08200	18- 4	93501-04011
8- 5	92901-06100	23- 8	92901-08600	18- 7	93503-16010
8- 7	92901-06100	24- 8	92901-08600	6-12	93507-32009
8-19	92901-06100	24-45	92901-08600	6- 9	93509-32012
13-16	92901-06100	18-16	92901-10100	3-22	93603-08072
16- 3	92901-06100	3-15	92901-12100	11- 6	93603-14026
16- 7	92901-06100	11- 3	93101-10001	4-12	93606-06091
19-25	92901-06100	3-13	93102-20009	23- 9	94140-08138
20-16	92901-06100	5-29	93102-26042	24- 9	94140-08138
22- 7	92901-06100	3-18	93103-28011	23-10	94240-08044
23-27	92901-06100	33-33	93104-07003	24-10	94240-08044
24-23	92901-06100	24-14	93104-21016	24-38	94504-20089
24-32	92901-06100	23-15	93105-47007	24-39	94604-20001
25-21	92901-06100	23-14	93106-20001	1-18	94701-00039

NUMERICAL INDEX

Ref No.	Parts No.	Ref No.	Parts No.	Ref No.	Parts No.
19- 7	95301-05600	6-15	98501-05010		
19-17	95301-05600	28-25	98501-05010		
26-22	95301-05600	11-13	98501-05020		
1-13	95301-06600	28- 8	98501-05020		
22- 6	95301-06600	19- 5	98501-05025		
23-28	95301-06600	19-15	98501-05025		
24-33	95301-06600	11-14	98501-05035		
24-24	95301-06600	20-15	98501-06015		
25-22	95301-06600	20-11	98503-03006		
26-18	95301-06600	9-11	98503-04015		
28-13	95301-06600	8-16	98512-03008		
23- 6	95301-08600	12-13	98701-05015		
24- 6	95301-08600	11- 7	98901-04008		
27-13	95301-08600				
24-43	95301-08700				
14- 4	95301-10600				
18-15	95301-10600				
19-22	95301-10700				
14- 9	95304-12800				
13-20	95701-08100				
13- 9	95821-08015				
13- 6	95821-08120				
15- 7	97201-08015				
26-11	97301-06012				
28-20	97301-06012				
13-15	97301-06015				
16- 2	97301-06015				
16- 6	97301-06015				
26- 2	97301-06015				
19-24	97301-06015				
26-15	97301-06020				
23- 7	97301-08015				
7-19	97311-06025				
24- 7	97321-08015				
10- 7	97321-08018				
9-24	98302-03012				
2- 6	98501-04005				
9-21	98501-04010				
14-12	98501-05008				



YAMAHA MOTOR CO., LTD.

PRINTED IN JAPAN
First edition Apr., 1975
(592-28198-E5)